

ORDER NO. **ARP2527** 

COMPACT DISC PLAYER

### PD-S95 AND PD-95 HAVE THE FOLLOWING:

Tuna	Mo	del	Davies Baguirament	Paradia
Туре	PD-S95	PD-95	Power Requirement	Remarks
KU/CA	0	_	AC120V only	
HEM	-	0	AC220-230V, 240V (switchable) *	

<sup>\*</sup> Change the connection of the power transformer's primary wiring.

- This manual is applicable to PD-S95/KU/CA and PD-95/HEM.
- Ce manuel pour le service comprend les explications de réglage en français.
- Este manual de servicio trata del método ajuste escrito en español.

### CONTENTS

1.	SAFETY INFORMATION	2
2.	LABEL CHECK ······	з
3.	PACKING AND PARTS LIST	4
4.	EXPLODED VIEWS AND PARTS LIST	5
5.	SCHEMATIC AND PCB CONNECTIONS	
	DIAGRAMS	14
6.	PCB PARTS LIST	31
7.	ADJUSTMENTS	36
7.	REGLAGES ·····	51
7.	AJUSTES ·····	66
8.	IC INFORMATION	81
9.	DISASSEMBLY	82
10.	PANEL FACILITIES	83
11.	SPECIFICATIONS	84

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A. PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
© PIONEER ELECTRONIC CORPORATION 1992

SN MAY. 1992 Pi

SN MAY. 1992 Pinted in Japan

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

#### WARNING

Lead in solder used in this product is listed by the California Health and Welfare agency as a known reproductive toxicant which may cause birth defects or other reproductive harm (California Health & Safety Code, Section 25249.5).

When servicing or handling circuit boards and other components which contain lead in solder, avoid unprotected skin contact with the solder. Also, when soldering do not inhale any smoke or fumes produced.

### 1. SAFETY INFORMATION


-(FOR USA MODEL ONLY)-

#### 1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

#### LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5mA.



ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

#### 2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a  $\Delta$  on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which dose not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

### 2. LABEL CHECK

### - (FOR EUROPEAN MODEL ONLY) -

VARO!

AVATTAESSA JA SUOJALUKITUS OHITETTAESSA OLET ALTTIINA NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE. ÄLÄ KATSO SÄTEESEEN.

ADVERSEL:

USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION UNDGÅ UDSAETTELSE FOR STRÅLING.

VARNING!

OSYNLIG LASERSTRÅLNING NÄR DENNA

DEL ÄR ÖPPNAD OCH SPÄRREN

ÄR URKOPPLAD. BETRAKTA EJ STRÅLEN.



LASER Kuva 1 Lasersateilyn varoitusmerkki

WARNING! -

DEVICE INCLUDES LASER DIODE WHICH EMITS INVISIBLE INFRARED RADIATION WHICH IS DANGEROUS TO EYES. THERE IS A WARNING SIGN ACCORDING TO PICTURE 1 INSIDE THE DEVICE CLOSE TO THE LASER DIODE.



laser radiation

LASER
Picture 1
Warning sign for


- IMPORTANT -

THIS PIONEER APPARATUS CONTAINS LASER OF CLASS 1.

SERVICING OPERATION OF THE APPARATUS SHOULD BE DONE BY A SPECIALLY INSTRUCTED PERSON.

MAXIMUM OUTPUT POWER: 5 mw
WAVELENGTH: 780-785 nm

### **HEM** type



Additional Laser Caution —

1. Laser Interlock mechanism

The ON/OFF status of the clamp switch (S 102) for detecting loading completion is detected by the system microprocessor, and the design prevents laser diode oscillation when the clamp switch is OFF.

Thus, the interlock will no longer function if the clamp switch (S 102) is deliberately shorted.

In the test mode the interlock mechanism will not function (refer to page 36).

Laser diode oscillation will continue if pin 4, 5, or 29 of CXA 1081 S(IC 1) is connected to ground or the terminals of Q 304 are shorted each other (fault condition).

 If the fault condition described in 1 is induced with the cover removed and the objective lens extending past the outer circumference of the disc clamper diameter, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 laser beam.

**HEM** type

### 3. PACKING AND PARTS LIST

#### NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The  $\triangle$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "O" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

### **Parts List**

Mark	No.	Description	Part No.		Mark	No.	Description	Part No.
	1	Styrol protector (F)	PHA1176		NSP	101	Battery (R03, AAA)	VEM - 022
	2	Styrol protector (R)	PHA1177		NSP	102	Turn table rubber	PEB1187
	3	Packing case (PD-95)	PHG1814		NSP	103	Spacer (rubber)	PEB1174
		Packing case (PD-S95)	PHG1815		NSP	104	Earth lead unit	PDF1129
	4	Connection cord	PDE1032		1101	201	(PD-S95 only)	1 21 1120
		(PD-95 only)					(1 D Goo Gilly)	
	5	(English/French)	PRE1165					
		Operating instructions (German/Italian/Dutch/						
		Swedish/Spanish/Portug (PD-95 only)	uese)					
	6	Wireless remote	PWW1056				ļ	
	_	control unit					,	103 13
	7	Battery cover	PZN1009				!	/ /
	8	Cord with mini plug (PD-S95 only)	PDE - 319					
	9	Mirror mat	VHL1012				! >	/ :
	10	Vinyl bag	Z21 - 037					·~/
	11	Vinyl bag	Z21 - 038				1	į
	12	Caution label	PRW1246					turntable of the
	13	Sheet	PRW1245				tray assembly	y. ¦
	14	Table rubber assembly	PEA1174				<b>*</b>	:
	15	Video cord (PD-S95 only)		2		<u></u>	4,8,15	i; 1; 1;
	16	Styrol protector	PHC1057	<b>'</b> >	/ ,	$/\!\!/$	104 14,102 5	
	17 18	Caution Screw	PRM1025 PBA1065		//0	1	101	زلبر
							7 6 11	
					A.			
				10	N	$\checkmark$		
					12	$\langle \!                                   $		
						9	16 17	
						<u> </u>	18	
							$A \mid \emptyset $	_1
					_	/		>
				_	$\times$		$\downarrow \hspace{-0.5cm} \downarrow \hspace{-0.5cm} \searrow$	
					`	$\times$		>
						_	$\times$	
							3	
							<b>\</b>  /	

## 4. EXPLODED VIEWS AND PARTS LIST

### NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The  $\triangle$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "O" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

### 4.1 EXTERIOR


### **Parts List**

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
	1	1P pin jack (PD-95)	PKB1017		31	Screw	CPZ30P080FMC
$\Delta$	2	AC power cord (PD-95)	PDG1003		32	Side pole	PAN1224
$\overline{\Delta}$		AC power cord (PD-S95)			33	Side pole (R)	PAN1237
$\triangle$	3	Power transformer	PTT1254		34	Side spacer	PEB1197
_		(PD-95)			35	Caution label	PRW1244
$\Delta$		Power transformer	PTT1251				
		(PD-S95)			36	Table assembly	PEA1255
$\Delta$	4	Power transformer	PTT1255		37	Over tray	PNW2079
_		(PD-95)			38	Screw	PBA1064
	5	3P receptacle (PD-95)	PKP1006		39	Spindle base assembly	PXA1421
		-			40	Holder	VNL - 268
$\triangle$	6	Power transformer	PTT1256				200
		(PD-95)			41	Damper sheet	PNM1125
	7	Screw	IBZ30P080FCC		42	Damper rubber	PEB1146
	8	Upper board (F)	PNS1026		43	E ring	YE30FUC
	9	Side board	PAN1225		44	Rotor assembly	PXA1392
	10	Upper board (R)	PAN1227		45	Spring	PBH1092
					_		
	11	Washer	WH40FUC		46	Turn table	PAN1267
	12	Cord clamper	RNH - 184		47	Screw	BBZ30P060FCC
	13	Power button	PAC1610	$\Delta$	48	Ground terminal	DKE - 101
	14	Plate assembly	PXA1465	<del></del>		(PD-S95)	2112 101
	15	Screw	IBZ30P060FCC	$\Delta$	49	BNC connectors	PKB1018
				ω.		(PD-S95)	11121010
	16	Screw	PMZ26P060FNI			(-2 300)	
	17	Screw	PDZ30P050FCC	NSP	101	PCB mold	AMR1525
	18	Screw	IBZ30P180FCC	NSP	102	Rear base (PD-S95)	PNA1712
	19	Screw	IBZ40P080FCC	NSP		Rear base (PD-95)	PNA1894
NSP	20	Screw	BBT30P080FCC	$\Delta$	103	Strain relief	CM - 22B
				_		(PD-95)	
	21	Screw	IBZ30P100FCC	NSP		Strain relief	PNW2145
NSP	22	Main board assembly	PWZ2212			(PD-S95)	
		(PD-95)		NSP	104	Side angle	PNB1328
NSP		Main board assembly	PWZ2213	NSP	105	Audio case (PD-95)	PNB1332
		(PD-S95)		-		, , , , , , , , , , , , , , , , , , , ,	
$\odot$	23	Analog board assembly	PWM1529	NSP	106	Switch angle	PNB1373
		(PD-95)		NSP	107	Sash A	PAN1192
	24	Screw	PBA1049		108	Stopper (rubber)	PEB1148
	25	Tape	PNM1129	NSP	109	Base plate	PNA1711
				NSP	110	PCB spacer (PD-95)	PNY - 404
	26	Screw	IBZ30P150FCU			• • • • • • • • • • • • • • • • • • • •	
	27	Screw	IBZ30P060FCC	NSP	111	Single mechanism	PXA1461
	28	•••••				assembly	
	29	Screw	VBA1027	NSP	112	Tray assembly	PXA1447
	30	Plate	PBK1090	NSP	113	Plate spring ST	PBK1089
				NSP	114	PCB angle	PNB1205
				NSP	115	Spacer	PNM1019
							· ·

Mark	No.	Description	Part No.
NSP	116	Transfer Printer	PWZ2217
		assembly (PD-95)	
NSP		Transformer primary assembly (PD-S95)	PWZ2218
NSP	117	Thrust holder	PNB1325
NSP	118	Rear panel (PD-95)	PAN1258
NSP		Rear panel (PD-S95)	PAN1259
NSP	119	Tray	PNA1782
NSP	120	Tray locker	PNW2014
NSP	121	Mechanism cover	PNB1402
NSP	122	Slide guide	PNW2080
NSP	123	Rack	PNW2081
NSP	124	Collar	PNW2012
NSP	125	Trans roof	PNB1331
NSP	126	AC shield plate	PNB1330
NSP	127	Angle (PD-95)	PNB1333
NSP	128	PCB angle M	PNB1334
NSP	129	PCB angle A (PD-95)	PNB1372
NSP	130	Edge cover 11 (PD-95)	PEC1018
NSP	131	Edge cover 15	PEC1019
NSP	132	Edge guard (B)	DEC1144
NSP	133	Plate	PAN1263
NSP	134	Tray rubber	PEB1198
NSP	135	Tray holder B	PNW2077
NSP	136	Line L board assembly (PD-95)	PWZ2320
NSP	137	Line R board assembly	PWZ2321
NSP	138	Ballance L board assembly (PD-95)	PWZ2223
NSP		BNC board assembly (PD-S95)	PWZ2326
NSP	139	Ballance R board assembly (PD-95)	PWZ2225

6

5




\_

### 4.2 FRONT PANEL AND BOTTOM VIEW SECTION

### Parts List

•	Part	s List											
A	Mark	No. Description	Part No.	Mark	No.	Description	Part No.	-		<del>-</del>		٦	
A	<b>☆</b> <b>☆</b>	<ul> <li>23P F.F.C/30V (PD-95)</li> <li>25P F.F.C/30V (PD-95)</li> <li>2 Button</li> <li>3 Control button</li> <li>4 Display window</li> <li>5 FL sheet (PD-95)</li> <li>FL sheet (PD-S95)</li> </ul>	5) PDD1069 PDD1096 PAC1649 PAC1619 PAM1536 PAM1535 PAM1580	NSP NSP NSP NSP NSP NSP	112 F 113 S 114 S	nside beam Rear beam (PD-95) Rear beam (PD-S95) Rear beam L (PD-95) Rear beam L (PD-S95) Rear beam R (PD-S95) Rear beam R (PD-S95) Rear Beam R (PD-S95)	PNS1039 /	.''	14		• Front Panel Section		A
-		6 Display plate (PD-95) Display plate (PD-S95) 7 Front mask 8 LED cover 9 Side rubber 10 Front panel assembly (PD-95) Front panel assembly (PD-S95)	PAN1189 PAM1263 PAN1245 PEB1150 PEB1196 PEA1238			18	9	2	14				
В	NSP	<ul> <li>11 Control panel</li> <li>12 Lens L</li> <li>13 Indicater lens</li> <li>14 Screw</li> <li>15 Operate A board assembly (PD-95)</li> </ul>	PNW2076 PNW1860 PNW1893 BBZ26P080FCC PWZ1998			0			3 15	8		Bottom View Section	, В     
	NSP	Operate A board assembly (PD-S95)	PWZ2000		7								1
-		16 LED cover (S) 17 Screw 18 Earth plate S 19 FL sheet 20 Insulator	PEB1167 PMA30P080FCU PBK1100 PNM1149 PLA1097	19			17		0 9	2			
С	NSP	21 Stopper 22 Screw 23 Screw 24 Screw 25 Screw	PNM1156 IBZ40P150FCC BBT30P080FCC BBZ40P080FZK IBZ30P080FCC			5		Accessories control pane	s for the				       c
		26 Washer 27 Screw	WC40FCU BBZ40P300FZK				14	/ Winter paint					
_		101 Front angle 102 Name plate 103 Front panel (PD-95) Front panel (PD-S95) 104 Plate spring K 105 Base plate	PNB1329 PAN1262 PAN1256 PAN1257 PBK1087 PNA1711			7	6 3			25		-25	
	NSP	106 Operate B board assen 107 Absorber (sponge) 108 Senser plate 109 Under base 110 Front beam	nblyPWZ1999 PNM1116 PNM1154 PNA1710 PNS1034					; ; ; ;		24 20 20	25	24 25	
D								 	Note:Remove the No. 27 screw removing the tray assemb	22 22 when		24	D    -  -
7	9	1	1	2		ı	3		4		5	6	·
-			-			-		•		•	1	~	•


.



4.3 MECHANISM UNIT

В

D



# 1 I o V	ni¶ All	2 1 1 0 V	Pin Ke	2 1 I o V	.el	s i l o V	niq AN
E 2 10F 3	6 <b>*</b>	o .e	33	0 .0	21	0 .0	1
2. 0	0 \$	5. 0	34	9. O	81	9 'L	z
0 0	ις	0 .0	32	9. 0	61	1 .S	ε
0 0	25	o 'S	36	0 .0	0 Z	0 ·S	Þ
0 '0	23	o .e	18	0 .0	12	o .c	S
0 .0	24	0 9	8 E	0 ·S	22	o 's	9
0 .0	99	0 .0	3 8	6 '7	23	p 'G	L
0 .0	99	0 .0	0+	5. 0	τZ	0 .0	8
0 .0	78	F 3 toF t	17	0 .0	SZ	0 ·S	6
0 .0	88	0 .0	45	0 .0	9 Z	0 .ð	01
0 .0	6\$	0 .0	E #	0 .0	12	0 2	11
0 .0	0 9	0 .0	**	0 -0	8 Z	E 101 E 1	21
0 .0	19	0 .0	S 7	6 .4	6 Z	o .è	ει
2. 5	29	0 .0	9 7	6 '7	30	0 'S	71
0 .0	£ 9	0 .0	14	0 0	3.1	0 .0	2 L
2. 5	1/9	5° 0	8 1	0 .0	35	0 .2	9 t

s )	۱۰۸	Pin No.	s	100	. No.	6 )	100	aiq Ah	8	100		
ε.	ı	19	0	.0	1 7	0	0	51	S	.z.	ı	_
0 .	0	Z 9	0	.0	45	21	.0	22	0	.S	7	
0 .	0	£ 9	0	.0	43	0	.0	53	ç	.z	3	_
0 .	0	<b>†</b> 9	0	.0	* *	0	.0	5.4	8	.s.	*	_
0 -1	0	9 9	0	.0	9 7	0	.č	S 2	4	٠,	ç	_
0 .	0	99	0	.0	9 7	0	·s	9 2	s	٦-	9	
0 .	0	19	0	.0	11	ç	.s	12	0	.č	1	
s :	Z	8 9	0	.0	8 10	0	·s	8 Z	,	·z	8	_
<b>S</b> .	2	69	0	.0	6 tr	6	-1	6 Z	*	.z	6	
£ .:	z	0 1	0	.0	0 9	6	·1	30	0	.0	0	ı
0 '	S	12	ε	.s.	ις	0	<sup>-</sup> 0	1 &	8	-1	ı	ı
0 .	0	Z 1	0	.0	25	0	.0	32	0	.0	2	ı
0	S	ΕL	z	.S.	83	0	.e	33	0	.5	ε	ı
0 .	0	†L	z	.s	75	0	.0	34	0	.č	Þ	1
•	z	5 L	0	.0	55	0	.0	3 2	0	-S	S	ı
3	z	9 2	0	-0	9 9	0	.0	3 8	0	.5	9	ı
ε .	7	11	0	2.	15	0	.0	1 €	0	.0	1	1
s :	z	8 L	0	.0	8 \$	0	.0	38	0	·s	8	ı
ç .	z	61	0	.0	6 S	0	.0	3 8	0	.0	6	ı
\$ 7	Z	08	3	1	09	0	.0	0 >	0	.8	0	Z


0 0	8 %	0 .0	32	5. 0	91
2. 0	27	9. 0	1 8	0 .0	SI
2° 2	9 7	2. 0	30	0 .0	+1
6. 231.06. 28	42	9.0	5 2	S .0	ει
0 .0	* *	2.0	8 Z	0 .0	Z 1
2. 0	43	2 - 0	72	S .0	ΙΙ
2. S	7 7	0 .0	9 Z	0 .0	01
0 '9	14	-2. 0	52	0 .0	6
2. 5	0 1	9.0	24	0 .0	8
0 °S	3 8	i 'r-	23	0 .0	2
Z. 4	38	0 .0	22	0 .0	9
3. 5	37	0 ,0	12	0 .0	S
2. 3	3 6	0 .0	20	0 0	Þ
2. 3	35	0 -0	6 L	0 0	3
S. 5	34	0 .0	8 f	0 0	2
S. 5	33	0 .0	LI	-2. 0	l
#110A	Äo.	* 1 1 0 A	No.	*110V	.en
	ai9	- V , G X	*14	- · · · · ·	*!#
		(8	8 2 8	(CXA10	105

o .e	30	1 .E-	SI
0 .0	82	0 0	71
2. 0	8 Z	1 0-	Εt
2. 4	72	2 .1-	1.5
2. 5	9 Z	0 .0	11
0 .0	S 2	0 .0	01
1 '2-	24	0 .0	6
0 .1-	23	0 .0	8
0 .0	22	0 0	2
6 '7-	12	8 .4-	9
0 .0	01	2.8	S
0 .0	6 L	2. 4	*
0 .0	8 f	0 .0	ε
9 '9-	21	£ '1	z
-3. 0	9 t	0 .0	1
2 1 1 0 V	.oN	21 [ o V	.o.M
- • 1 • X	*!4	1.07	*!#
	(518	(CXA10	10

1 C 1 1 (N J M T 8 0


PD-S95, PD-95


### Parts List




	Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
			_					
Α		1	Lever switch	DSK1003		51	•••••	
		2	Screw	PBA1064		52	Washer	WT32D080D050
		3	Float spring (A)	PBH1098		53	•••••	
		4	Float spring (B)	PBH1099		54	Screw	PMA26P040FCU
		5	Spring	PBH1112		55	•••••	
		6	Float spring (C)	PBH1113		- 56	Screw ·	BPZ26P060FCU
		7	Float spring (D)	PBH1114		57	Washer	WT31D054D013
		8	Belt	PEB1138		58	Screw	IPZ30P060FCU
_		9	Damper rubber	PEB1146		<b>59</b>	Screw	ZMD30H040FBT
		10	Stopper (rubber)	PEB1085		60	Screw	IBZ30P120FCC
		11	Screw	PMZ30P350FCU		61	Screw	BMZ26P050FCU
		12	Roller	PNW2037		62	Screw	PMZ26P040FCU
		13	•••••			63	Screw	IBZ30P080FCC
		14	Gear	PNW1097		64	Screw	PDZ30P060FCC
		15	Motor pulley	PNW1643		٠.		122001 0001 00
		16	Cam	PNW1816	NSP NSP	101	Connector assembly (6P)	
В		17	Synchronize gear	PNW1817	NSP	102	Connector assembly (4P)	
_		18	Gear pulley	PNW1870	NSP	103 104	Felt Synchronize gear shaft	PED - 047
		19	Single gear	PNW1878	NSP	105	Gear angle	PLA1079 PNB1320
		20	Plate	PNW2013	1131	103	Gear angle	FNB1320
					NSP	106	Deck	PNB1323
		21	Loading base L	PNW2050	NSP	107	Bottom plate	PNB1335
		22	Loading base R	PNW2051	NSP	108	Base plate	PNB1322
		23	DC motor assembly	PEA1225	NSP	109	Collar	PNW2012
		24	Weight	PNB1232	NSP	110	U guide	PNW1880
		25	Screw	PBA1024			_	
		00	C	TT 4 10 T 4	NSP	111	Servo mechanism assembl	
		26	Screw	PBA1054	NSP	112	Collar	PBE1002
		27 28	Spring	PBH1028	NSP	113	Cushion rubber (2.5)	PEB - 304
		29	Spring Spring	PBH1029	NSP	114	Magnet	PMF1006
		30	Rivet	PBK1021 PBM - 015	NSP	115	Side yoke	PNB1046
					NSP	116	Center yoke	PNB1047
		31	Stopper (rubber)	PEB1035		117	Sheet	PNM - 042
^		32	Holder rubber	PEB1048		118	Tape	PNM - 044
С		33	Guide bar	PLA1026		119	Linear flexible cable	PNP1022
		34	Shaft	PLA1027		120	Carriage	PNR1034
		35	Disc table	PLA1088	110D		<b>-</b>	
		36	Roller	PLM1001		121	Bobbin (A)	PNW1205
		37	Adjust lever	PNB1048		122	Bobbin (B)	PNW1206
		38	Spindle motor assembly	PEA1224		123	Mechanism base unit	PNW2078
		39	Pickup assembly	PWY1004		124	Blind sheet	PNM1112
		40	Screw	BBZ30P060FCC	NSP	125	Earth lead unit	PDF1074
			_					
		41	Screw	IPZ30P120FCU				
		42	Screw	PMZ26P030FCU				
		43	Screw	PMZ26P060FCU				
		44	Screw	PMZ30P080FCU				
		45	Screw	PMZ30P160FCU				
		46	Washer	WS30FMC				
		47	Washer	WT26D047D025				
D		48	**************************************			•	•	
5		49	Drive unit	PEA1222				
		50	Speed detect unit	PEA1223				


## 5. SCHEMATIC AND PCB CONNECTIONS DIAGRAMS










\_









С

D

1. RESISTORS:

Indicated in  $\Omega$ , 1/4W, 1/6W, 1/8W,  $\pm 5\%$  tolerance unless otherwise noted k; k $\Omega$ , M; M $\Omega$ , (F);  $\pm 1\%$ , (G);  $\pm 2\%$ , (K);  $\pm 10\%$ ,(M);  $\pm 20\%$  tolerance.

2. CAPACITORS:

Indicated in capacity ( $\mu$ F) /voltage (V) unless otherwise noted p; pF. Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE CURRENT:
; DC voltage (V) in play mode.

←mA; DC current in play mode.

; Value in ( ) is DC current in stop mode.

4. OTHERS:

В

С

D

→; Signal route.

∅ ; Adjusting point

The  $\triangle$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation. \* marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

5. SWITCHES (The underlined indicates the switch position)

PRIMARY BOARD ASSEMBLY S301: POWER ON - OFF

OPERATE A BOARD ASSEMRLY

S401: TRK FF S402: TRK REV S403: PAUSE S404: PLAY S405: 0/C S406: STOP

OPERATE B BOARD ASSEMBLY


S407: DISPLAY OFF S408: OUT SEL


IC513 (PD0116A)


C 5	513 (PD0116A)					22 (PD2	0 2 8 1	В)	. !	I C 5 2 3 (P D 2 0 2 8 B)					
in Io.	Volts	Pia No.	Volts		Pin No.	Volts	Pin No.	Volts		Pin No.	Volts	Pin No.	Volts		
1	25	15	5. 0		1	0. 0	15	5. 0	] [	1	0. 0	15	5. 1		
2	2. 4	16	0. 0		2	2. 5	16	5. 0	] [	2	2. 6	16	5. 1		
3	5. 0	17	5. 0		3	2. 2	17	5. 0		3	2. 3	17	5. 0		
4	0. 0	18	NC		4	0. 0	18	0. 0		4.	0. 0	18	0. 0		
5	NC	19	0. 0		5	5. 0	19	3. 6	$  \  $	5	5. 1	19	3. 7		
6	2. 4	20	2. 4		6	5. 0	20	1. 7		6	5. 1	20	1. 7		
7	2. 6	21	0. 0		7	2. 3	21	1. 8		7	2. 4	21	1. 8		
8	0. 0	22	5. 0		8	2. 5	22	1. 8		8	2. 5	22	1. 8		
9	2. 3	2 3	1. 9		9	0. 0	23	0. 0		9	0. 0	23	0. 0		
0	5. 0	2 4	1. 9		10	5. 0	24	0. 0		10	5. 1	24	0. 0		
1	NC	2 5	3. 6		11	0. 0	2 5	0. 0		11	0. 0	2 5	0. 0		
2	NC	26	2. 1		12	2. 3	26	2. 7		1 2	2. 3	26	2. 9		
3	NC	27	2. 4		13	2. 5	27	0. 0		1 3	2. 5	27	0. 0		
4	4. 7	28	2. 5		14	0. 0	28	5. 0		14	0. 0	28	5. 1		
									•						

### Waveforms

Note: The encircled numbers denote measuring points in the







### 6. PCB PARTS LIST

### NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- Parts marked by " " are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The  $\triangle$  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%)

	$\rightarrow$ 56 × 10 <sup>1</sup> $\rightarrow$ 561 · · · · · · RD1/4PS 5 6 1 J
	$\rightarrow$ 47 × 10 <sup>3</sup> $\rightarrow$ 473 ····· RD1/4PS 4 7 3 J
	→ 0R5 ····· RN2H 0 R 5 K
1Ω	→ 010 ······ RS1P 0 1 0 K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
LIST	OF AS	SEMBLIES			Q524, 525 T	TRANSISTOR	DTC124ES
					Q554-557	TRANSISTOR	2SC3068
PD-S							201122
⊙		ASSEMBLY	PWM1363		Q558		2SK364
NSP		E B BOARD ASSEMBLY	PWZ1999		Q559, 560 I	FET	2SJ104
NSP	-OPERAT	E A BOARD ASSEMBLY	PWZ2000		Q561		2SK364
						TRANSISTOR	2SC3068
∍		ARD ASSEMBLY	PWM1525		Q621 TRANS	SISTOR	2SC1740SLN
ISP	-MAIN B	OARD ASSEMBLY	PWZ2213				
NSP	-PRIMAR	Y BOARD ASSEMBLY	PWZ2218		Q622 TRANS	SISTOR	2SA933SLN
ISP	∟BNC BO	ARD ASSEMBLY	PWZ2326	$\Delta$	Q661 TRANS	SISTOR	2SC3179
				$\Delta$	Q662 TRANS	SISTOR	2SA1262
					Q800, 801 1	TRANSISTOR	2SC3068
PD-9	95				Q850, 851 1	TRANSISTOR	2SC3068
<b>ວ</b> ື		ASSEMBLY	PWM1362				
NSP		E B BOARD ASSEMBLY	PWZ1999		D521 DIODE	3	1SS292
NSP		E A BOARD ASSEMBLY	PWZ1998		D550, 551 I		1SS292
.01	0. 5.2				D570, 571 I		1SS292
<b>①</b>	MOTHER RO	DARD ASSEMBLY	PWM1524	$\Delta$	D610-613 I		10DF2
NSP		OARD ASSEMBLY	PWZ2212	$\stackrel{\Delta\Sigma}{\Lambda}$	D620-627 I		10DF2
NSP		Y BOARD ASSEMBLY	PWZ2217	445	D020 021 1	) TODE	1001 8
				•	D672 674 1	ZENER DIODE	HZ5CLL
NSP		CE L BOARD ASSEMBLY	PWZ2223	Δ			
NSP		CE R BOARD ASSEMBLY	PWZ2225		D800, 801 I		1SS292
NSP		BOARD ASSEMBLY	PWZ2320		D850, 851 I	TODE	1SS292
ISP	-LINE K	BOARD ASSEMBLY	PWZ2321	0011	TDANCE	ODMEDO	
_				COILS	•	ORMERS	
<b>O</b>	ANALOG BO	OARD ASSEMBLY	PWM1529			AXIAL INDUCTOR	LAU010K
					L513, 514		PTH1006
						AXIAL INDUCTOR	LAU010K
<u>ANA</u>	LOG B	OARD ASSEMI	BLY	,		AXIAL INDUCTOR	LAU010K
(PD-	95 only	/)			L551-554 I	FERRITE BEAD	VTH1024
SEMIC	CONDUC.	TORS			L564		PTH1006
	IC501, 502	REGULATOR IC	NJM7805FA				
	IC512 L00		TC74HCU04AP	CAPA	CITORS		
	IC513 IC		PD0116A			AUDIO FILM CAPACITOR	CFTXA104J50
		D/A CONVERTER IC	PD2028B		-	AUDIO FILM CAPACITOR	CFTXA103J50
		OP-AMP IC	NJM2114D			r. CAPACITOR	CENA101M25
	10004, 000	O Ami IC	N3M2114D			AUDIO FILM CAPACITOR	CFTXA104J50
<b>A</b>	10000 001	IC PROTECTOR	ICP-N15			FILM CAPACITOR	CFTXA103J50
⚠					COOR MODIC	FILM CAPACITOR	CL1VW102120
<b>A</b>		OP-AMP IC	NJM2114D		CE10 LIBY	A DILM CADACITOD	CCTVA 479 LEA
<b>♠</b>		GULATOR IC	NJM7818FA			FILM CAPACITOR	CFTXA473J50
<b>1</b>		GULATOR IC	NJM7918FA			AUDIO FILM CAPACITOR	CFTXA103J50
	IC800 OP-	-AMP IC	NJM2114D			FILM CAPACITOR	CFTXA473J50
						FILM CAPACITOR	CFTXA103J50
	IC850 OP-		NJM2114D		C516 ELECT	r. CAPACITOR	CENA102M16
	Q521 TRAN		DTC124ES				
	0522, 523	TRANSISTOR	DTA124ES		C517, 518(	(2P/100)	PCH1105

Mark	No.	Description	Part No.	Mark	No.	Description	Part No.
	C519 ELECT.	CAPACITOR	CENA102M16	RESIS'	TORS		
	C520 ELECT.		CEAS331M50			BONFILM RESISTOR	RD1/6PM105J
		FILM CAPACITOR	CFTXA473J50			BONFILM RESISTOR	
							RD1/6PM□□□J
	C322 AUDIO F	FILM CAPACITOR	CFTXA682J50			SONFILM RESISTOR	RD1/4PM J
	CEAR CERTAIN	CADACTEON (0.01)	DCI 1000			CARBONFILM RESISTOR	RD1/6PM
		C CAPACITOR(0.01)	PCL1029		K505 MEI7	AL OXIDE RESISTOR	RS1LMFJ
	C524 ELECT.		CENA102M16				
		FILM CAPACITOR	CFTXA104J50			CARBONFILM RESISTOR	RD1/6PM□□□J
		FILM CAPACITOR	CQMA473J50			SONFILM RESISTOR	RD1/4PM□□□J
	C528 ELECT.	CAPACITOR	CENA102M16		R520, 521	CARBONFILM RESISTOR	RD1/6PM□□□J
					R522 MET/	AL OXIDE RESISTOR	RS1LMF J
	C529 MYLAR F	FILM CAPACITOR	CQMA473J50		R524 MET/	AL OXIDE RESISTOR	RS1LMF J
	C530, 531 AUD	DIO FILM CAPACITOR	CFTXA682J50				
	C532 ELECT.	CAPACITOR	CENA102M16		R526, 527	CARBONFILM RESISTOR	RD1/6PM□□□J
		ILM CAPACITOR	CFTXA104J50			CARBONFILM RESISTOR	RDR1/4PM□□□J
	C535 ELECT.		CENA102M16			CARBONFILM RESISTOR	RDR1/4PM□□□J
			•••••			CARBONFILM RESISTOR	RDM1/2P
	C538 539 CER	RAMIC CAPACITOR	CCCCH120J50			SONFILM RESISTOR	RD1/6PM
	C542, 543 MIC		CMA181J500		1012 0/114	ON TEM NEOTOTON	
	C544, 545 MIC		CMA330J500		DE72 E74	CARBONFILM RESISTOR	RDM1/2P□□□J
		DIO FILM CAPACITOR	CFTXA473J50		•		
	•					SONFILM RESISTOR	RD1/6PM□□□J
	C550, 551 MIC	A CAPACITOR	CMA181J500			CARBONFILM RESISTOR	RDM1/2P
	OFFO FFO WYO		CH1 000 1500			CARBONFILM RESISTOR	RD1/6PM
	C552, 553 MIC		CMA330J500		R588-593		RDM1/2P□□□J
		OIO FILM CAPACITOR	CFTXA104J50				<u></u>
		CCT. CAPACITOR	CENA102M16			CARBONFILM RESISTOR	$RDR1/4PM \square \square \square J$
		OIO FILM CAPACITOR	CFTXA104J50			CARBONFILM RESISTOR	RDR1/2PM□□□J
	C560-563 MIC	CA CAPACITOR	CMA470J500	1	R661-666	CARBONFILM RESISTOR	RDR1/4PM J
				1	R671,672	CARBONFILM RESISTOR	RDR1/4PM J
	C564, 565		CFTXA681J50	1	R801-813	CARBONFILM RESISTOR	RDM1/2P□□□J
	C566, 567		CFTXA562J50				
	C568-571 ELE	CCT. CAPACITOR $(22 \mu)$	VCH1070	1	R851-863	CARBONFILM RESISTOR	RDM1/2P□□□J
		CT. CAPACITOR $(47 \mu)$	PCH1094				
		CT. CAPACITOR	CENA102M16	OTHER	RS		
						RES (OSC)	PSS1011
	C578 579 AUD	OIO FILM CAPACITOR	CFTXA103J50				1001011
	C580 CERAMIC		CCCCH120J50	OPE	RATE	B BOARD ASSEM	MRIV
		ILM CAPACITOR	CFTXA104J50	<b>V.</b> L.	17-11-6-	B BOAND ACCE	
		OIO FILM CAPACITOR	CFTXA683J50	SEMIC	ONDUC	TORS	
		TILM CAPACITOR	CFTXA473J50			ions	CI II 2 AVC2II2
	C200 MODIO F	ILM CAPACITOR	CF1AA415J50		D403 LED	I PD	SLH-34YC3H3
	OF47 FAA DID	OT 04D401T0D/00/00\	PCII1 000		D404, 405	LED	SLH-34VC3H3
		CT. CAPACITOR (22/35)		CMITO			
	C589 ELECT.		CENA102M16	SWITC			
		TILM CAPACITOR	CFTXA104J50	,	5407, 408	SWITCH	PSG-065
		TILM CAPACITOR	CFTXA682J50				
	C593, 594 ELE	CT. CAPACITOR	CENA102M16		SITORS		
				(	C410, 411	AXIAL CERAMIC C.	CCPUCH100J5(
		TILM CAPACITOR	CFTXA104J50				
		TILM CAPACITOR	CFTXA103J50	RESIST			
	C597 ELECT.	CAPACITOR	CENA102M16	1	R414 CARE	ONFILM RESISTOR	RD1/6PM□□□J
	C598 AUDIO F	TILM CAPACITOR	CFTXA103J50				— <del>-</del>
	C600 ELECT.	CAPACITOR	CENA102M50	OPE	RATE	A BOARD ASSEM	MBLY
	C610610 ASIN	OIO FILM CAPACITOR	CFTXA103J50	CEMIC	ONDUC'	rope	
		CT. CAPACITOR					PROCES
			CENA222M35		IC401 FL		PDG036
		OIO FILM CAPACITOR	CFTXA563J50		-	SISTOR	2SC1740S
	•	CT. CAPACITOR	CENA100M50			TRANSISTOR	DTA124ES
	C663, 664 AUD	OIO FILM CAPACITOR	CFTXA563J50		0401 LED		AA0045
				I	0402 LED		BR0045
		CT. CAPACITOR	CENA471M50				
		CT. CAPACITOR	CENA010M50	SWITC			
		CT. CAPACITOR	CENA100M50		5401-406	SWITCH	PSG-065
		CT. CAPACITOR $(47 \mu)$					
	C802, 803 ELE	CT. CAPACITOR	CENA471M35	COILS/	TRANSI	FORMERS	
				I	401, 402	AXIAL INDUCTOR	LAU010K
	C850, 851 ELE	CT. CAPACITOR $(47 \mu)$	PCH1094				•
		CT. CAPACITOR	CENA471M35	CAPAC	ITORS		
						T. CAPACITOR	CEJA330M16
32						•	· ***= =

Mar	k No.	Description	Part No.	Mark	No.	Description	Part No.
		O FILM CAPACITOR	CFTXA103J50		Q25		DTA124ES(PD-95)
		MIC CAPACITOR	CGCYF473Z25			[RANSISTOR	2SC1740SLN
		AXIAL CERAMIC C.	CCPUCH100J50	_	Q304 TRANS		2SA1399
	C412 CERA	MIC CAPACITOR	CKCYF103Z50	Δ	D5, 6 DIODI	3	10E2
RES	ISTORS			$\Delta$	D7-10		31DF2-FC5
	R401, 402	CARBONFILM RESISTOR	RD1/6PM□□□J	$\overline{\Lambda}$	D11 ZENER	DIODE	HZ27-1/2L
		CARBONFILM RESISTOR	RD1/6PM□□□J	$\Delta\!$	D12 ZENER	DIODE	HZ20-1L
		STOR ARRAY (47K)	RA10S□□□J	$\Delta\!$	D17-20		31DF2-FC5
		CARBONFILM RESISTOR	RD1/6PM□□□J	$\Delta$	D21-26 DIC	DDE	11ES2
		CARBONFILM RESISTOR	RD1/6PM□□□J				
	R418 CARBO	ONFILM RESISTOR	RD1/6PM471J(PD-S95)		D146		1SS254 (PD-95)
	DAIO CADD	OMELIA DECICTOR	RD1/6PM331J(PD-95)		D147 DIODE		1SS254
	K419 CARD	ONFILM RESISTOR	RD1/6PM391J(PD-S95) RD1/6PM331J(PD-95)		D148 DIODE D181-183 I		1SS254 (PD-S95)
	PASO CAPR	ONFILM RESISTOR	RD1/6PM471J(PD-S95)		D701-704 I		1SS254 1SS292 (PD-S95)
	N420 CAND	JATTLM RESISTOR	RD1/6PM331J(PD-95)		D720-723 I		1SS292 (FD-595)
			ND1/01 M0013 (1 D 33)		D120-123 L	TODE	133292
TH	ERS		0001010 51		,	ORMERS	
	REMOTE SEI		SBX1610-51		L3 RADIAL	INDUCTOR	LFA010K
	CN401 CON	NECTOR	HLEM25R-1 (PD-S95)		L4 COIL		PTL1003
	V401 FL T	ממו	HLEM23R-1 (PD-95) PEL1025		L5-9 L16-40		PTH1006
		MIC RESONATOR	VSS1014		L10-40 L41 COIL		PTH1006
	A4UI CERAI	IC RESONATOR	1551014		L41 COIL		PTL1003 (PD-S95)
NΑ	IN BOAF	RD ASSEMBLY			L43		PTH1006
					L51 AXIAL	INDUCTOR	LAU010K
SEM	ICONDUCT	= =					
	IC1 PRE A		CXA1081S		CITORS		
		CONTROL IC EMODULATION IC	CXA1082BS			TILM CAPACITOR	CFTXA472J50
		COMPUTER, IC	CXD1167Q PD3179B		C5 ELECT.	IIC CAPACITOR	CCCCH300J50 CENA221M25
	IC9 IC	COMPUTER, IC	MC74HCU04N		C7 ELECT.		CENA221M25 CENA221M25
	103 10		IIIC / 411C0041V			CAPACITOR	CGCYF473Z25
	IC10 SYSTI	EM RESET IC	M51957AL		CO CERTIFIC	CM ACTION	COCII 41 5225
£	IC11 REGUI		NJM7805FA		C10 ELECT.	CAPACITOR	CEAS101M10
_	IC12 OP-AM		NJM2114D			FILM CAPACITOR	CFTXA333J50
$\hat{oldsymbol{\Lambda}}$	IC13 REGUI	LATOR IC	AN7810F		C12 ELECT.	CAPACITOR	CENA101M25
$\hat{\mathbf{L}}$	IC14 REGUI	LATOR IC	AN7910F		C13 AUDIO	FILM CAPACITOR	CFTXA332J50
					C14 AUDIO	FILM CAPACITOR	CFTXA103J50
	IC15 REGUI		NJM7812FA				
_	IC16 REGUI		NJM7912FA			CAPACITOR	CENA101M25
Å		OWER OP-AMP	TA8410K			CAPACITOR	CEASR47M50
<u>↑</u>	IC20 S. REC		NJM431L AN7810F			FILM CAPACITOR	CFTXA103J50
Ĺ	ICZI REGUL	LATUR IC	VIALOIDE			CAPACITOR FILM CAPACITOR	CENA471M16 CFTXA333J50
À	IC22 REGUI	ATOR IC	AN7910F		CEI MUDIO	FILM CAPACITON	CLIVU999190
À	IC23 S. REC		NJM431L		C22 ELECT	CAPACITOR	CEASR47M50
Ŷ		PROTECTOR	ICP-N10		C23 ELECT.	CAPACITOR	CENA101M25
	IC101 IC		MC74HCU04N(PD-S95)			CT. CAPACITOR	CEAS101M25
	IC181, 182	IC	NJM072DE			CAPACITOR	CENA101M25
					C27 AUDIO	FILM CAPACITOR	CFTXA153J50
	IC721 REGU		NJM78L05A				
	Q4 TRANSIS		DTC124ES		C29		CFTXA152J50
	Q6 TRANSIS		2SC1740SLN			IO FILM CAPACITOR	CFTXA104J50
	Q7 TRANSIS		2SA933SLN		C33		CFTXA102J50
	Q8, 9 TRANS	SISTOR	2SC1740SLN			CAPACITOR	CEAS470M10
	O10 TRANCE	CTOD	2041200		C35 AUDIO	FILM CAPACITOR	CFTXA104J50
£	Q10 TRANSI Q11 TRANSI		2SA1399 2SC3179		CSE ELECT	CAPACITOR	CENATOTHE
<b>7</b>	Q11 1RANSI Q12. 13 TRA		2SA1262			FILM CAPACITOR	CENA101M25 CFTXA473J50
7	Q14 TRANSI		2SC3179			CAPACITOR	CENA102M16
	Q15 TRANSI		2SB715			CAPACITOR	CENA102M16
						FILM CAPACITOR	CFTXA124J50
	Q16 TRANSI	STOR	2SD755				<b></b>
	Q20, 21		DTA124ES(PD-95)			CAPACITOR	CEAS101M10
	Q22 TRANSI		DTC124ES			FILM CAPACITOR	CFTXA223J50
	Q23 TRANSI	STOR	DTC124ES(PD-S95)		C45 AUDIO	FILM CAPACITOR	CFTXA104J50
							33

Mark N	lo. Description	Part No.	Mark	No.	Description	Part No.
	AUDIO FILM CAPACITOR LECT. CAPACITOR	CFTXA103J50 CENA101M25		C152, 153	ELECT. CAPACITOR	CEAS330M35
C48 C49 C50 C51	ELECT. CAPACITOR  AUDIO FILM CAPACITOR  ELECT. CAPACITOR	CEAS3R3M50 CFTXA472J50 CEAS330M35 CFTXA102J50		C161 CERA C164 CERA C166, 167	CERAMIC CAPACITOR MIC CAPACITOR MIC CAPACITOR CERAMIC CAPACITOR CERAMIC CAPACITOR(0.01)	CKCYF103Z50 CKCYF103Z50 CKCYF103Z50 CKCYF103Z50 PCL1029
C53 C54 C55 C56	C CERAMIC CAPACITOR  MYLAR FILM CAPACITOR  AUDIO FILM CAPACITOR  ELECT. CAPACITOR  AUDIO FILM CAPACITOR  AUDIO FILM CAPACITOR  AUDIO FILM CAPACITOR	CQMA471J50 CFTXA224J50 CENA102M35 CFTXA103J50 CFTXA103J50		C181 ELEC C182 AUDI C183 AUDI	CERAMIC CAPACITOR (0.01) T. CAPACITOR O FILM CAPACITOR O FILM CAPACITOR MIC CAPACITOR	PCL1029 CEAS101M25 CFTXA103J50 CFTXA332J50 CCCSL101J50
C61 C67 C68 C69	, 62 AUDIO FILM CAPACITOR	CFTXA104J50 CFTXA68JJ50 CFTXA104J50 CEASR33M50 CFTXA103J50		C187 AUDI C188 CERA C191-193	ELECT. CAPACITOR O FILM CAPACITOR MIC CAPACITOR AUDIO FILM CAPACITOR AUDIO FILM CAPACITOR	CEAS330M35 CFTXA332J50 CCCSL150J50 CFTXA103J50 CFTXA103J50
C80 C81 C82 C83	ELECT. CAPACITOR CERAMIC CAPACITOR CERAMIC CAPACITOR CERAMIC CAPACITOR CERAMIC CAPACITOR SELECT. CAPACITOR	CEAS470M50 CKCYF103Z50 CCCSL680J50 CGCYF473Z25 CEAS101M25		C203, 204 C206-209 C211, 212	O FILM CAPACITOR CERAMIC CAPACITOR(0.01) CERAMIC CAPACITOR(0.01) CERAMIC CAPACITOR(0.01) MIC CAPACITOR	PCL1029
C86 C87 C88 C90	CERAMIC CAPACITOR ELECT. CAPACITOR ELECT. CAPACITOR DIEDECT. CAPACITOR DIEDECT. CAPACITOR(3300) DIEDECT. CAPACITOR	CCCCH300J50 CEAS330M35 CEAS101M50 PCH1104 CENA102M35	1	C720 CERA C721 (0. 47	MIC CAPACITOR MIC CAPACITOR F/S. 5) MIC CAPACITOR	CCCSL101J50(PD-S95) CGCYF473Z25 PCH1062 CKCYF103Z50 CFTXA103J50
C32	, so beder on nerron		RESIS	TORS		
C98 C99 C10	6,97 ELECT. CAPACITOR 6 ELECT. CAPACITOR 10 ELECT. CAPACITOR 10,101 ELECT. CAPACITOR(3300) 12,103 ELECT. CAPACITOR	CENA221M25 CEAS100M50 CEAS101M50 PCH1104 CENA222M16		R9-13 CAR R14 CARBO R16-22 CA	ONFILM RESISTOR BONFILM RESISTOR NFILM RESISTOR RBONFILM RESISTOR RBONFILM RESISTOR	RDR1/4PM
C10 C10 C11	14,105 AUDIO FILM CAPACITOR 16,107 AUDIO FILM CAPACITOR 18,109 CERAMIC CAPACITOR 1 ELECT. CAPACITOR 2 AUDIO FILM CAPACITOR	CFTXA103J50 CFTXA104J50 CCCCH101J50 CEAS101M10 CFTXA473J50	]	R31,32 CA R34-41 CA R43-51 CA	FILM RESISTOR RBONFILM RESISTOR RBONFILM RESISTOR RBONFILM RESISTOR NFILM RESISTOR	RN1/6PQF RDR1/4PM
C11	3 AUDIO FILM CAPACITOR 4 ELECT. CAPACITOR 5 CERAMIC CAPACITOR 7	CCCSL331J50 (PD-S95) CFTXA103J50 CENA470M25 CKCYF103Z50 CCCSL471J50 (PD-95) CCCSL331J50 (PD-S95)	] ] ]	R58,59 CA R60 CARBO R61 CARBO	RBONFILM RESISTOR RBONFILM RESISTOR NFILM RESISTOR NFILM RESISTOR RBONFILM RESISTOR	RD1/6PM□□□J RDR1/4PM□□□J RD1/6PM□□□J RDR1/4PM□□□J RD1/6PM□□□J
C11 C11 C12 C12	8 AUDIO FILM CAPACITOR 9 CERAMIC CAPACITOR 10 ELECT. CAPACITOR 11 AUDIO FILM CAPACITOR 15 CERAMIC CAPACITOR	CFTXA473J50 CKCYF103Z50 CENA470M25 (PD-S95) CFTXA103J50 (PD-S95) CKCYF103Z50 (PD-S95)	] ] ]	R74-76 CA R81-83 CA R84 CARBO	RBONFILM RESISTOR RBONFILM RESISTOR RBONFILM RESISTOR NFILM RESISTOR NFILM RESISTOR	RDR1/4PM J RD1/6PM J RD1/6PM J RDR1/2PM J RDR1/2PM J
C12 C12 C13 C13	77 CERAMIC CAPACITOR 18 CERAMIC CAPACITOR 10,131 CERAMIC CAPACITOR 14 AUDIO FILM CAPACITOR 15 CERAMIC CAPACITOR	CKCYF103Z50 CKCYF103Z50 (PD-S95) CKCYF103Z50 CFTXA103J50 CCCCH120J50 (PD-S95)	i i i	R90 CARBO R100.101 ( R104 CARB	NFILM RESISTOR NFILM RESISTOR CARBONFILM RESISTOR DNFILM RESISTOR DNFILM RESISTOR	RD1/6PM
C13 C14 C14	6 CERAMIC CAPACITOR 1 CERAMIC CAPACITOR 7, 148 ELECT. CAPACITOR 1 CERAMIC CAPACITOR	CCCCH330J50 (PD-S95) CCDSL101J50 CENA331M25 CKCYF103Z50	F F	R108-111 ( R112, 113 ( R114 CARBO	ONFILM RESISTOR CARBONFILM RESISTOR CARBONFILM RESISTOR ONFILM RESISTOR CARBONFILM RESISTOR	RDM1/2P750J(D-S95) RDR1/4PM□□□ J RD1/6PM□□□ J RDR1/4PM□□□ J RD1/6PM□□□ J

Mark	No. Description	Part No.	Mark No.	Description	Part No.
	R117 R119-121 CARBONFILM RESISTOR R123 CARBONFILM RESISTOR	RDM1/2P102J(PD-95) RDR1/4PM□□□J RD1/6PM□□□J	(PD-95 only)	R BOARD ASSE	EMBLY
	R124-129 CARBONFILM RESISTOR R131, 132 CARBONFILM RESISTOR R133-135 CARBONFILM RESISTOR	RDR1/4PM□□□J RDR1/4PM□□□J RD1/6PM□□□J	CAPACITORS C892 C894		CFTXA102J50 CFTXA102J50
	R136-139 CARBONFILM RESISTOR R141, 142 CARBONFILM RESISTOR R143, 144 CARBONFILM RESISTOR	RDR1/4PM□□□J RDR1/4PM□□□J RD1/6PM□□□J	(PD-95 only)	BOARD ASSE	MBLY
	R146 R147 R148 R149 R150 CARBONFILM RESISTOR	RDR1/4PM103J(PD-95) RD1/60M331J(PD-95) RDM1/2P102J(PD-95) RD1/6PM331J(PD-95) RDR1/4PM□□□J	CAPACITORS  C891 C893  LINE L BOAF	RD ASSEMBLY	CFTXA102J50 CFTXA102J50
	R151-157 CARBONFILM RESISTOR	RD1/6PM DJ	(PD-95 only)		
	R158, 159 R160 CARBONFILM RESISTOR	RDM1/2P102J (PD-S95) RDR1/4PM103J (PD-S95)	COILS/TRANSFO L540 FILTER F584 FILTER		PTH1011 VTH1001
	R161-167 CARBONFILM RESISTOR R168 R178 CARBONFILM RESISTOR	RD1/6PM□□□J RDM1/2P□□□J RDM1/2P□□□J	LINE R BOAF (PD-95 only)	RD ASSEMBLY	
	R181-193 CARBONFILM RESISTOR R194-196 CARBONFILM RESISTOR R303, 304 R701 CARBONFILM RESISTOR	RD1/6PM□□□J RDR1/4PM□□□J PCX1024 (PD-95) RD1/6PM244J (PD-S95)	COILS/TRANSFO L541 FILTER F585 FILTER		PTH1011 VTH1001
	R702 CARBONFILM RESISTOR R721 CARBONFILM RESISTOR VR2 SEMI-FIXED RESISTOR	RD1/6PM102J(PD-S95) RD1/6PM□□□J VRTB6VS103	BNC BOARD (PD-S95 only		
	VR3-7 VR VR8 VR VR9 VR VR10 VR	VRTB6VS223 VRTS6VS102 VRTB6VS473 VRTS6VS472	CAPACITORS C751 CERAMIC	C CAPACITOR	CKCYF103Z50
ОТНЕ					
	CN1 CN2 CN6 CONNECTOR	52045-1710 5597-05CPB HLEM25S-1 (PD-S95) HLEM23R-1 (PD-95)			
	DL1, 2 FILTER JA2 JACK	PTF1009 PKB1004			
	JA3 JA701,702 JACK X1 CERAMIC RESONATOR X2 XTAL RES (OSC)	TOTX174 RKN1004 (PD-S95) RSS1033 PSS1019 (PD-S95)			
TRA	NSFORMER PRIMARLY	ASSEMBLY			
SWIT	CHES S301 POWER SWITCH	PSA1002			
COIL.	S/TRANSFORMERS L301 FILTER	PTL1002			
CAPA A	ACITORS  C301  C302-304 CAPACITOR (CERAMIC)	VCG-048 (PD-95) VCG-048			
OTHE ⚠	ERS TERMINAL	RKC-061			

### 7. ADJUSTMENTS

Perform the following adjustments in the indicated order.

#### Adjustments

- 1. Tracking error offset, focus error offset and RF offset adjustment.
- 2. Tracking return offset adjustment.
- 3. Focus lock and spindle lock check.
- 4. Grating adjustment.
- 5. Tracking balance adjustment.
- 6. Tangential adjustment
- 7. Radial adjustment
- 8. RF level check
- 9. Focus gain adjustment
- 10. Tracking gain adjustment
- 11. VCO free-running frequency adjustment
- 12. Method of focus error check

#### Measuring Devices

- 1. Dual-trace oscilloscope
- 2. Light power meter
- 3. YEDS-7 test disc
- 4. Focus and tracking adjustment filter
- 5. Loop gain adjustment band-pass filter
- 6. Signal generator
- 7. Grating driver
- 8. General-use tools
- 9. Commercial available disc (8 cm and 12 cm)
- 10. Hex. wrenchdriver (GGK 1002, 1.5 mm)

#### About the test mode

### How to activate and release the test mode

- ① To activate the test mode, turn ON the power switch with the test mode jumper short-circuited.
- ② The test mode is released by turning the power switch OFF.

The functions of the keys in the test mode are outlined in Table 1.

### Adjustment Volume Name

VR2: RF offset (RF. OF)

VR3: Focus gain (FO. GA)

VR4: Tracking gain (TR. GA)

VR5: Tracking balance (TR. BL)

VR6: Focus error offset (FO. OF)

VR7: Tracking error offset (TE. OF)
VR8: VCO frequency counter (VCOA)

VR9: Tracking return offset (TR. OF)

VR10: RF level (RF.LEV)





Fig.1 Adjusting point

In the test mode, closing and opening of servos is performed independently. Therefore, to set the play mode the servos have to be closed in (serial) sequence. Remember that in the test mode the play mode can't be set simply by pressing PAUSE ( ) key.

For example, to set the play mode from the stop mode, press the following keys in the indicated order.



\* In the test mode, servos keep a serial sequence.

#### Function of Each Key in the Test Mode

Symbol	Key name	Function during test mode	Description			
<b>&gt;&gt;</b>	TRACK FWD	Focus servo close	Lights the laser diode and sets the focus actuator UP/DOWN to close the focus servo.			
<b>&gt;</b>	PLAY	Spindle servo close	After kicking the spindle motor, it closes the servo in the CLV-H mode.			
ir .	PAUSE	Tracking servo close/open	Performs a toggle operation. When pressed, the tracking sevo is closed and the unit enters the play mode (the focus servo and spindle servo should be already closed). At this time the PAUSE indicator lights. If pressed again, the tracking servo opens.			
	ОИТРИТ	Carriage reverse (inward)	Moves the carriage inwards at high (approx. 1 cm/s) speed. Since there is no safety device to stop the carriage, be sure to sto manually in time.			
	DISPLAY	Carriage forward (outward)	Moves the carriage outwards at high (approx. 1 cm/s) speed. Since there is no safety device to stop the carriage, be sure to stop it manually in time.			
	STOP	Stop	Stops all servos and returns the unit to the initial condition.			
<b>A</b>	OPEN/CLOSE	(Disc tray) open/close	Opens and closes the disc tray. However, the pickup does not return to the rest position when the tray is opened. It does not move either when the tray is closed.			

Table 1.

Step	Oscillosc	ope setting	Test points	Adjusting	Check items/	Adjustment procedure
No.	٧	Н		points	specifications	
1	Tracking	error offse	t, focus error	offset and R	F offset adjustm	ent
		TP1	TP1 Pin 4 (TR. ER)	VR7 (TE. OF)	0V ± 50 mV	<ul> <li>Set the test mode. (*)</li> <li>Adjust VR7 (TE. OF: tracking error offset) so that the voltage at Pin 4 (TE: tracking error) of TP1 becomes 0V ± 50 mV.</li> </ul>
		TP1	TP1 Pin 6 (FO. ER)	VR6 (FO.OF)	0V ± 50 mV	<ul> <li>Adjust VR6 (FO. OF: focus error offset) so that the voltage at Pin 6 (FO. ER: focus error) of TP1 becomes 0V ± 50 mV.</li> </ul>
		TP1	TP 1 Pin 1 (RF)	VR2 (RF. OF)	100 mV ± 50 mV	Adjust VR2 (RF. OF: RF offset) so that RF output voltage at Pin 1 of TP 1 becomes 100 mV ± 50 mV.
2	Tracking	return offs	et adjustmen	t	.1	
		TP1	TP1 Pin 2 (TR. RT)	VR9 (TR. OF)	0V ± 10 mV	<ul> <li>Set the test mode. (*)</li> <li>Adjust VR9 (TR. OF: tracking return offset) so that the voltage at Pin 2 TR. RT (tracking return) of TP1 becomes 0V ± 10 mV.</li> </ul>
3	Focus lo	ck and spir	ndie lock ched	k		<u> </u>
	V 0.5V/div	H 100 msec /div	TP 1 Pin 1 (RF output)		RF output  Clockwise rotation	<ul> <li>Load the disc.</li> <li>Set the test mode. (*)</li> <li>Move the pickup close to the center of the disc using DISPLAY Key.</li> <li>Be sure to perform this operation.</li> <li>Observe Pin 1 RF (RF output) of TP 1 with an oscilloscope and confirm that RF signal is output after pressing TRACK FWD key (▶►).</li> <li>Press PLAY key (▶) and confirm that the disc rotates clockwise at approx. normal speed (about 300 rpm around the center of the disc), without running wildly or in reverse direction.</li> </ul>

<sup>\*</sup> See Page 36.

Step	Oscillosc	ope setting	Test points	Adjusting	Check items/	Adina
No.	V	н	1 vac points	points	adjustment specifications	Adjustment procedure
4-1	Grating a	djustment	(1) (with an 8	cm disc)		
	1V/div	5 ms/div	TP1 Pin 4 (TR. ER)  L.P.F.  39k Ω  Fig. 2.	Grating	Null point	<ul> <li>This adjustment can be performed with an 8 cm disc having pits over a 75 mm in diameter.</li> <li>Load the disc. (8 cm)</li> <li>Set the test mode. (*)</li> <li>Press TRACK FWD (▶►) and PLAY (▶) keys in that order to close the focus and spindle servos (the tracking servo is open state.)</li> <li>Press DISPLAY key and move the pickup to the outer track of the 8 cm disc. When moving the pickup, it is possible to insert a slotted screwdriver in the grating adjustment plate slot from above the unit. (Fig. 3.)</li> <li>Observe the waveform at Pin 4 TR. ER (tracking error) of TP1 with an oscilloscope and at this time, insert cut off 4 kHz low-pass filter (Fig. 2).</li> <li>Insert the tracking driver in the adjustment slot and turn it so as to find out the null point (Photo-1).</li> </ul>

\* See Pag≽ 36.

Step	Oscillos	cope setting	Test points	Adjusting	Check items/	Adjustment procedure
No.	٧	Doints		specifications		
4-2	Grating	adjustment	(2) (with an 1	2 cm disc pla	ying more than	60 minutes)
	1V/div	5 ms/div	TP1 Pin 4 (TR. ER)	Grating	Null point	<ul> <li>Load the disc (playing more than 60 minutes).</li> <li>Set the test mode. (*)</li> <li>Press TRACK FWD (▶►) and PLAY (▶) keys in that order to close the focus and spindle servos (the tracking servo is open state).</li> <li>Press DISPLAY key and move the pickup to the outer track of the disc. When moving the pickup, it is possible to insert a slotted screwdriver in the grating adjustment plate slot from above the unit. (Fig. 3.)</li> <li>Observe the waveform at Pin 4 TR. ER (tracking error) of TP1 with an oscilloscope and at this time, insert cut off 4 kHz low-pass filter. (Fig. 2.)</li> <li>Insert the tracking driver in the adjustment</li> </ul>
		TD: !	L.P.F.			slot and turn it so as to find out the null point (Photo-1).
		TP1	39k Ω			
	(	Pin5 (GND)	0.001/	/F Oscillos	scope side	
			Fig. 2			
				Grating	Maximum amplitude	■ Turn the grating driver slowly clockwise from the null point and set to at the first point where the waveform amplitude (tracking error signal) is maximum. (See photo-2)

<sup>\*</sup> See Page 36.





Fig. 3. Grating Adjustment



Step	Oscilloso	ope setting	Test points	Adjusting	Check items/ adjustment	Adjustment procedure
No.	ν	н		points	specifications	, i
5	Tracking	g balance ad	ljustment			
	0.5V/div	5 msec/div	TP1 Pin 4 (TR. ER)	VR5 (TR. BL)	* A + + B - +	Load the disc. Set the test mode. (*) Press DISPLAY key and move carriage close to the center track of the disc. Press TRACK FWD (▶►) and PLAY (▶) keys in that order to turn the disc. Observe Pin 4 TR. ER (tracking error) of TP1 with an oscilloscope. And adjust VR5 TR. BL (tracking balance) so as to remove DC elements from the tracking error waveform.  A=B
VAN PARAMETER CONTRACTOR CONTRACT			Photo-6			Photo-7

<sup>\*</sup> See Page 36.





Fig. 4. Tangential Adjustment



Step	Oscillosco	ope setting	Test points	Adjusting	Check items/	Adjustment procedure
No.	V	н	Took points	points specifications		Adjustment procedure
6	Tangentia	al adjustme	ent			
			TP 1 Pin 1 (RF output)	Tangential adjustment screw	Eye pattern optimum point	<ul> <li>Load the disc.</li> <li>Set the test mode. (*)</li> <li>Press DISPLAY key and move the pickup to the center track of the disc (set it to such a location that the tangential screw can be seen from above the servo mechanism. (See fig. 4.)</li> <li>Press TRACK FWD (▶►), PLAY (▶) and PAUSE (■) keys in that order to close all servos. (Pause indicator lights.)</li> <li>Observe Pin 1 RF (RF output) of TP 1 with an oscilloscope and adjust the tangential screw so that the eye pattern becomes clear. (Fig. 4.)</li> <li>The adjustment point is located around the middle location between the point where the eye pattern becomes blurred when turning the tangential screw clockwise and the point where the eye pattern becomes blurred when turning the adjustment screw counterclockwise.</li> <li>Observe the overall clearness of the waveform and one of the diamond shapes in the eye pattern (photo-9). Optimum adjustment is attained at the point where diamond shape lines are relatively thin.</li> </ul>
					Pin5	
					(GND)	Fig. 5

<sup>\*</sup> See Page 36.

Step	Oscilloscope setting		Test points	Adjusting	Check items/	Adjustment procedure
No.	٧	н	Total politica	points	specifications	wolnstrue ir brocadus
7	Radial ad	justment				
			TP1 Pin 1 (RF output)	Radial adjustment screw	Eye pattern optimum point	<ul> <li>Load the disc.</li> <li>Set the test mode. (*)</li> <li>Press DISPLAY key and move the pickup to the center track of the disc (set it to such a location that the tangential screw can be seen from above the servo mechanism. (See fig. 4.)</li> <li>Press TRACK FWD (▶►), PLAY (▶) and PAUSE (■) keys in that order to close all servos. (Pause indicator lights.)</li> <li>Observe Pin 1 RF (RF output) of TP 1 with an oscilloscope and adjust the tangential screw so that the eye pattern becomes clear. (Fig. 4.)</li> <li>The adjustment point is located around the middle location between the point where the eye pattern becomes blurred when turning the tangential screw clockwise and the point where the eye pattern becomes blurred when turning the adjustment screw counterclockwise.</li> <li>Observe the overall clearness of the waveform and one of the diamond shapes in the eye pattern (photo-9). Optimum adjustment is attained at the point where diamond shape lines are relatively thin.</li> <li>Perform the tangential and radial adjustments alternately two or more times.</li> </ul>
					Pin1 (RF)	
					Pin5 (GND)	Fig. 5

\* See Page 36.

Step No.	Oscilloscope setting		Test points	Adjusting	Check items/ adjustment	Adjustment procedure
	V	н	1 est points	points	specifications	, , , , , , , , , , , , , , , , , , ,
8	RF level c	heck				
			TP 1 Pin 1 (RF)  TP 1 Pin 1 (RF)	Check VR 10	1.5V <sup>+0.2V</sup> 1.5V <sup>+0.2V</sup>	<ul> <li>Set the test mode. (*)</li> <li>Connect the probe of the oscilloscope to Pin 1 RF (RF output) of TP 1.</li> <li>Play back the disc, measure the RF waveform p-p voltage and confirm that it becomes 1.5V <sup>+0.2V</sup><sub>-0V</sub>.</li> <li>Adjust VR 10 if the voltage does not become 1.5V <sup>+0.2V</sup><sub>-0V</sub>.</li> </ul>

<sup>\*</sup> See Page 36.

Step No.	Oscilloscope setting		T	Adjusting	Check items/			
	٧	Н	Test points	points	adjustment specifications	Adjustment procedure		
9	Focus gain adjustment							
	CH1 (X) , CH2 (Y) 20 mV/div, 5 mV/div (probe 10:1)		X axis: TP1 Pin 5 (FO. IN) Y axis: TP1 Pin 6 (FO. ER)	VR3 (FO. GA)	Phase difference 90°  Pin7 (FO.IN)  Pin5 (GND)  Pin6 (FO.ER)	<ul> <li>With the power off, connect the oscilloscope and the oscillator as shown in Fig. 6.</li> <li>Set the normal playback mode.</li> <li>Turn the oscillators power on and set it to output a 1.2 kHz, 1 Vp-p signal.</li> <li>Note: (Some oscillators output DC when turned ON. In that case, connect the oscillator after turning it on.)</li> <li>Adjust VR3 FO. GA (focus gain) so that the resurge waveform on an oscilloscope becomes a horizontal circle (phase difference 90°).</li> </ul>		
					( )	Fig. 6.		
		h gain oto-11		Optimu Photo		Low gain Photo-13		

No.	Oscilloscope setting		Test points Adjusting	Check items/ adjustment	Adjustment procedure	
	V	Н		points	specifications	, , , , , , , , , , , , , , , , , , ,
10	Tracking	gain adju:	stment			
	CH1 (X), CH2 50 mV/div, 5 (Probe 10:1)		X axis: TP1 Pin 3 (TR. IN) Y axis: TP1 Pin 2	VR4 (TR. GA)	Phase difference 90°	<ul> <li>With the power off, connect the oscilloscope and the oscillator as shown in Fig. 7.</li> <li>Set the normal playback mode.</li> <li>Turn the oscillators power on and set it to output a 1 kHz, 2 Vp-p signal.</li> <li>Note: (Some oscillators output DC when turned on. In that case, connect the oscillator after turning it on.)</li> <li>Adjust VR4 TR. GA (tracking gain) so that the resurge waveform on an oscilloscope becomes a horizontal circle (phase difference 90 °).</li> </ul>
			TP1 Pin 2 (TR. ER)		Pin3 (TR.IN) Pin5 (GND) Pin4 (TR.ER)	000 Ω (10:1)  000 Ω  1kHz 2Vp-p  9kΩ  (10:1)  7  Fig. 7.
	-	n gain		Optimu		Low gain Photo-16
11	Phot	to-14	frequency adj	Photo		Low gain Photo–16
11	Phot	to-14	frequency adj	Photo		<del>-</del>

<sup>\*</sup> See Page 36.

12 Focus error check  Set the test mode. (*) Connect Pin 7 FO. IN (focus in) of TP1 GND.  1V/div 2 ms/div TP1 Pin 6 Check Waveform Press TRACK FWD key and check	Step	Oscilloscope setting		Test points	Adjusting	Check items/ adjustment	Adjustment procedure
1V/div 2 ms/div TP1 Pin 6 Check Waveform Set the test mode. (*) Connect Pin 7 FO. IN (focus in) of TP1 GND. Press TRACK FWD key and check waveform on Pin 6 FO. ER (focus error	No.	v	н	- roac points	points		Adjustment procedure
1V/div 2 ms/div TP1 Pin 6 Check Waveform © Connect Pin 7 FO. IN (focus in) of TP1 GND.  1V/div 2 ms/div TP1 Pin 6 (FO. ER) Waveform Waveform on Pin 6 FO. ER (focus error	12	Focus e	error check				
		1V/div	2 ms/div		Check	Waveform	<ul> <li>Connect Pin 7 FO. IN (focus in) of TP1 to GND.</li> <li>Press TRACK FWD key and check the waveform on Pin 6 FO. ER (focus error) of</li> </ul>

\* See Page 36.

# 7. REGLAGES

Effectuer les réglages suivants dans l'ordre indiqué.

### Réglages

- Réglage du décalage d'erreur d'alignement, du décalage d'erreur de mise au point et du décalage RF (fréquence radio).
- 2. Réglage du décalage de retour d'alignement.
- Contrôle du verrouillage de mise au point et du verrouillage d'axe.
- 4. Réglage du filtre.
- 5. Réglage de l'équilibre d'alignement.
- 6. Réglage tangentiel.
- 7. Réglage radial.
- 8. Contrôle du niveau RF (fréquence radio)
- 9. Réglage du gain de mise au point
- 10. Réglage du gain d'alignement
- 11. Réglage de la fréquence de relaxation du VCO (oscillateur à fréquence réglée par variation de tension)
- 12. Méthode de contrôle d'erreur de mise au point

### Appareils de Mesure

- 1. Oscilloscope à double trace
- 2. Indicateur de puissance lumineuse
- 3. Disc d'essai YEDS-7
- 4. Filtre de réglage de mise au point et d'alignement
- 5. Filtre passe-bande de réglage de gain de boucle
- 6. Générateur de signal
- 7. Excitateur de filtre
- 8. Outils à usage général
- 9. Disc disponible dans le commerce (8 cm et 12 cm)
- 10. Clé hex. (GGK 1002, 1.5 mm)

### Apropos du mode d'essai

### Mise en/hors service du mode d'essai

- ① Pour activer le mode d'essai, mettre l'interrupteur d'alimentation sous tension en court-circuitant le cavalier de mode d'essai.
- ② Le mode d'essai est annulé en ramenant l'interrupteur d'alimentation sur OFF.

Les fonctions des touches en mode d'essai sont décrites au Tableau 1.

### Nom des Résistances Variables de Réglage

VR2: Décalage RF (RF. OF)

VR3: Gain de mise au point (FO. GA)

VR4: Gain d'alignement (TR. GA)

VR5: Equilibre d'alignement (TR. BL)

VR6: Décalage d'erreur de mise au point (FO. OF)

VR7: Décalage d'erreur d'alignement (TE. OF)

VR8: Compteur de fréquence VCO (VCOA)

VR9: Décalage de retour d'alignement (TR. OF)

VR 10: Niveau RF (RF.LEV)





Fig.1 Points de réglage

Dans le mode d'essai, l'ouverture et la fermeture des circuits d'asservissement sont effectuées indépendamment. Par conséquent, pour régler le mode de lecture, les asservissements doivent être fermés l'un après l'autre (en série). Ne pas oublier que, dans le mode d'essai, le mode de lecture ne peut pas être réglé simplement en appuyant sur la touche PAUSE (

Par exemple, pour régler le mode de lecture à partir du mode d'arrêt, appuyer sur les touches suivantes dans l'ordre indiqué.



\* Dans le mode d'essai, les asservissements restent en séquence sérielle.

### ● Fonction de Chaque Touche dans le Mode D'essal

Symbole	Touche	Fonction en mode d'essai	Fait s'allumer la diode laser et déplace le dispositif de commande de mise au point dans le sens vertical pour fermer l'asservissement de mise au point.			
<b>₩</b>	TRACK FWD	Fermeture asservissement de mise au point				
<b>&gt;</b>	PLAY	Fermeture asservissement d'axe	Après le démarrage du moteur d'axe, ferme l'asservissement dans le mode CLV-H.			
11	PAUSE	Fermeture/ouverture asservissement d'alignement	Exécute une opération de bascule. Quand elle est enfoncée, l'asservissement d'alignement est fermé et l'appareil passe dans le mode de lecture (les asservissements de mise au point et d'axe doivent déjà être fermés). A ce moment-là le témoin de PAUSE s'allume. Si elle est de nouveau enfoncée, l'asservissement d'alignement s'ouvre.			
	ОИТРИТ	Retour du chariot (vers l'intérieur)	Déplace le chariot vers l'intérieur à grande vitesse (approx. 1 cm/s.). Comme il n'y a pas de dispositif de sécurité pour arrêter le chariot, il faut donc l'arrêter manuellement à temps.			
	DISPLAY	Avance du chariot (vers l'extérieur)	Déplace le chariot vers l'extérieur à grande vitesse (approx. 1 cm/s.). Comme il n'y a pas de dispositif de sécurité pour arrêter le chariot, il faut donc l'arrêter manuellement à temps.			
	STOP	Arrêt	Arrête tous les asservissements et ramène l'appareil à sa condition initiale.			
<b>A</b>	OPEN/CLOSE	Ouverture/fermeture du plateau de disc	Ouvre et ferme le plateau de disc. Le capteur ne revient cependant pas à la position d'arrêt quand le plateau est ouvert. Il ne se déplace pas non plus quand le plateau est fermé.			

Tableau 1.

Etape	Réglage de	l'oscilloscope	Points d'essai	Points de contr réglage spécifica	Eléments contrôlés/	Procédure de réglage				
No.	V	н			spécifications de réglage					
1	Réglage RF (fréq	du décalago uence radio	e d'erreur d'a )	lignement, dı	ı décalage d'err	eur de mise au point et du décalage				
		TP1	TP1 Pin 4 (TR. ER)	VR7 (TE. OF)	0V ± 50 mV	<ul> <li>Régler le mode d'essai. (*)</li> <li>Ajuster VR7 (TE. OF: décalage d'erreur d'alignement) afin que la tension à la broche 4 (TE: erreur d'alignement) de TP1 devienne 0V ± 50 mV.</li> </ul>				
		TP1	TP1 Pin 6 (FO. ER)	VR6 (FO.OF)	0V ± 50 mV	Ajuster VR6 (FO. OF: décalage d'erreur de mise au point) afin que la tension à la broche 6 (FO. ER: erreur de mise au point) de TP1 devienne 0V ± 50 mV.				
		TP1	TP1 Pin1 (RF)	VR2 (RF. OF)	100 mV ± 50 mV	<ul> <li>Ajuster VR2 (RF. OF: décalage RF) afin que la tension à la broche 1 de TP1 devienne 100 mV ± 50 mV.</li> </ul>				
2	Réglage	Réglage du décalage de retour d'alignement								
		TP1	TP1 Pin 2 (TR. RT)	VR9 (TR. OF)	0V ± 10 mV	<ul> <li>Régler le mode d'essai. (*)</li> <li>Ajuster VR9 (TR. OF: décalage de retour d'alignement) afin que la tension à la broche 2 (TR. RT: retour d'alignement) de TP1 devienne 0V ± 10 mV.</li> </ul>				
3	Contrôle	du verrouil	lage de mise	au point et du	ı verrouillage d'	axe				
	V 0,5V/div	H 100 msec /div	TP 1 Pin 1 (Sortie RF)		Sortie RF  Rotation dans le sens des aiguilles d'une montre	<ul> <li>Charger le disc.</li> <li>Régler le mode d'essai. (*)</li> <li>Amener le capteur près du centre du disc en utilisant la touche DISPLAY.         Toujours effectuer cette opération.     </li> <li>Observer la sortie RF à la broche 1 de TP 1 avec un oscilloscope et confirmer que le signal RF est sorti lorsque la touche TRACK FWD (▶►) est enfoncée.</li> <li>Appuyer sur la touche PLAY (▶►) et confirmer que le disc tourne dans le sens des aiguilles d'une montre à approximativement la vitesse normale (environ 300 tr/mn près du centre du disc), sans qu'il tourne irrégulièrement ou en sens inverse.</li> </ul>				

<sup>\*</sup> Voir Page 51.

Etape No.	Réglage de I	'oscilloscope H	Points d'essai	Points de réglage	Eléments contrôlés/ spécifications de réglage	Procédure de réglage
4-1	Réglage (	du filtre (1)	(avec un disc	: de 8 cm)	Teglage	
4-1	1V/div	5 ms/div	TP1 Pin 4 (TR. ER)  L.P.F.  39k Q  W  T 0.001 A	Filtre	Point nul	Ce réglage peut être effectué avec un disc de 8 cm ayant des microcuvettes sur un rayon supérieur à 75 mm.     Charger le disc. (8 cm)     Régler le mode d'essai. (*)     Appuyer sur les touches TRACK FWD (▶) et PLAY (▶) dans cet ordre pour fermer les asservissements de mise au point et d'ave (l'asservissement d'alignement est en état ouvert).     Appuyer sur la touche DISPLAY. et amener le capteur sur la piste extérieure du disc de 8 cm. Lors du déplacement du capteur, il est possible d'insérer un tournevis dans la fente de la plaque de réglage du filtre depuis le haut de l'appareil. (Fig. 3).     Observer la forme d'onde à la broche 4 (TR. ER: erreur d'alignement) de TP1 avec un oscilloscope et à ce moment-là, insérer un filtre passe-bas de coupure 4 kHz (Fig. 2).     Insérer le tournevis d'alignement dans la fente de réglage et le tourner afin de trouver le point nul (Photo-1).

<sup>\*</sup> Voir Page 51.

Etape No.		l'oscilioscope	Points d'essai	Points de réglage	Eléments contrôlés/ spécifications de	Procédure de réglage
40	V	H do films (0)	/ di	do 40 o do	réglage	
4-2	1V/div	5 ms/div	TP1 Pin 4 (TR. ER)  L.P.F.  39k \Q W	Filtre	Point nul	Charger le disc. (durée de lecture supérieure à 60 minutes).  Régler le mode d'essai. (*)  Appuyer sur les touches TRACK FWD (▶) et PLAY (▶) dans cet ordre pour fermer les asservissements de mise au point et d'axe (l'asservissement d'alignement est en état ouvert).  Appuyer sur la touche DISPLAY et amener le capteur sur la piste extérieure du disc. Lors du déplacement du capteur, il est possible d'insérer un tournevis dans la fente de la plaque de réglage du filtre depuis le haut de l'appareil. (Fig. 3).  Observer la forme d'onde à la broche 4 (TR. ER: erreur d'alignement) de TP1 avec un oscilloscope et à ce moment–à, insérer un filtre passe–bas de coupure 4 kHz (Fig. 2).  Insérer le tournevis d'alignement dans la fente de réglage et le tourner afin de trouver le point nul (Photo–1).
				Filtre	Amplitude maximum	■ Tourner lentement l'excitateur de filtre dans le sens des aiguilles d'une montre à partir du point nul et le régler au premier point où l'amplitude de la forme d'onde (signal d'erreur d'alignement) est maximum. (Voir photo-2).

<sup>\*</sup> Voir Page 51.




Fig. 3. Réglage du Filtre




Photo-1 Point nul Photo-2 Amplitude maximum




Photo-3 Hors du point nul

Etape	Réglage de l'oscilloscope		Points d'essai	Points de	Eléments contrôlés/	Procédure de réglage
No.	٧	н		réglage	spécifications de réglage	Procedure de regiage
5	Réglage	de l'équilibe	re d'aligneme	nt		
	0.5V/div	5 msec/div	TP1 Pín 4 (TR. ER)	VR5 (TR. BL)		<ul> <li>Charger le disc.</li> <li>Régler le mode d'essai. (*)</li> <li>Appuyer sur la touche DISPLAY et amener le chariot près de la piste centrale du disc.</li> <li>Appuyer sur les touches TRACK FWD (▶►) et PLAY (▶►) dans cet ordre pour faire tourner le disc.</li> <li>Observer la forme d'onde à la broche 4 (TR. ER: erreur d'alignement) de TP1 avec un oscilloscope. Et régler VR5 (TR. BL: équilibre d'alignement) afin d'éliminer les éléments CC de la forme d'onde d'erreur d'alignement.</li> </ul>
	# A - # B - #		Photo-6	A≠B	— A → A B →	A=B  Photo-7

\* Voir Page 51.





Fig. 4. Réglage Tangentiel



Etape No.		l'oscilloscope	Points d'essai	Points de réglage	Eléments contrôlés/ spécifications de	Procédure de réglage
	V	Н		rogiago	réglage	
6	Réglage	tangentiel				
			TP1 Pin 1 (Sortie RF)	Vis de réglage tangentiel	Point optimum de mire	<ul> <li>Charger le disc.</li> <li>Régler le mode d'essai. (*)</li> <li>Appuyer sur la touche DISPLAY et amener le capteur à la piste centrale du disc. (Le placer à un endroit où la vis tangentielle peut être vue depuis le haut du mécanisme d'asservissement. (Voir Fig. 4.).</li> <li>Appuyer sur les touches TRACK FWD (▶►), PLAY (▶) et PAUSE (♣) dans cet ordre pour fermer tous les asservissements. (Le témoin de pause s'allume).</li> <li>Observer la sortie RF broche 1 de TP 1 avec un oscilloscope et régler la vis tangentielle afin que la mire devienne claire. (Fig. 4.).</li> <li>Le point de réglage est situé vers la position médiane entre le point où la mire devient floue lorsque la vis tangentielle est tournée dans le sens des aiguilles d'une montre et le point où la mire devient floue lorsque la vis de réglage est tournée dans le sens inverse.</li> <li>Observer la netteté d'ensemble de la forme d'onde et une des formes en diamant dans la mire (Photo-9). Le réglage optimum est obtenu au point où les lignes de la forme en diamant sont relativement fines.</li> </ul>
•					Pin5	
					Pin5 (GND)	Fig. 5

\* Voir Page 51.

Etape No.	Réglage de l	l'oscilloscope	Points d'essai Points de réglage		Eléments contrôlés/ spécifications de réglage	Procédure de réglage
140,	٧	Н		regiage		
7	Réglage	radial				
			TP1 Pin 1 (Sortie RF)	Vis de réglage radial	Point optimum de mire	<ul> <li>Charger le disc.</li> <li>Régler le mode d'essai. (*)</li> <li>Appuyer sur la touche DISPLAY et amener le capteur à la piste centrale du disc. (Le placer à un endroit où la vis radiale peut être vue depuis le haut du mécanisme d'asservissement. (Voir Fig. 5.).</li> <li>Appuyer sur les touches TRACK FWD (▶►), PLAY (▶) et PAUSE (♣) dans cet ordre pour fermer tous les asservissements. (Le témoin de pause s'allume).</li> <li>Observer la sortie RF broche 1 de TP 1 avec un oscilloscope et régler la vis radiale afin que la mire devienne claire. (Fig. 4.).</li> <li>Le point de réglage est situé vers la position médiane entre le point où la mire devient floue lorsque la vis radiale est tournée dans le sens des aiguilles d'une montre et le point où la mire devient floue lorsque la vis de réglage est tournée dans le sens inverse.</li> <li>Observer la netteté d'ensemble de la forme d'onde et une des formes en diamant dans la mire (Photo-9). Le réglage optimum est obtenu au point où les lignes de la forme en diamant sont relativement, deux fois ou plus, les réglages tangentiel et radial.</li> </ul>
					PinI (RF) Pin5 (GND)	
						Fig. 5

<sup>\*</sup> Voir Page 51.


Etape	Réglage de l'oscilloscope		Points d'essai	Points de	Eléments contrôlés/	Procédure de réglage				
No.	٧	н		réglage	spécifications de réglage	1 10000010 00 109.095				
8	Contrôle	Contrôle du niveau RF (fréquence radio)								
			TP 1 Pin 1 (RF) TP 1 Pin 1 (RF)	Contrôle VR 10	1,5V +0,2V 1,5V +0,2V	<ul> <li>Régler le mode d'essai. (*)</li> <li>Connecter la sonde de l'oscilloscope à la sortie RF broche 1 de TP 1.</li> <li>Reproduire le disc, mesurer la tension c-c de la forme d'onde RF et confirmer qu'elle devient 1,5V +0.2V.</li> <li>Ajuster VR 10 si la tension ne devient pas 1,5V +0.2V.</li> </ul>				

<sup>\*</sup> Voir Page 51.

Etape No.	Réglage de l	l'oscilloscope H	Points d'essai	Points de réglage	Eléments contrôlés/ spécifications de	Procédure de réglage
9			mise au point		réglage	
	Réglage du gain de CH1 (X), CH2 (Y) 20 mV/div, 5 mV/div (Sonde 10:1)		Axe X: TP1 Pin 5 (FO. IN) Axe Y: TP1 Pin 6 (FO. ER)	VR3 (FO. GA)	Différence de phase 90°  Pin7 (FO.IN) Pin5 (GND) Pin6 (FO.ER)	<ul> <li>L'alimentation étant coupée, connecter l'oscilloscope et l'oscillateur comme indiqué sur la Fig. 6.</li> <li>Régler le mode de lecture normal.</li> <li>Mettre l'oscillateur sous tension et le régler pour sortir un signal 1 Vc-c, 1,2 kHz.</li> <li>Remarque: (Certains oscillateurs sortent CC lorsqu'ils sont mis sous tension.         <ul> <li>Dans ce cas, connecter l'oscillateur après l'avoir mis sous tension).</li> </ul> </li> <li>Ajuster VR3 (FO. GA: gain de mise au point) afin que la forme d'onde de choc sur l'oscilloscope devienne un cercle horizontal (différence de phase 90°).</li> </ul>
	A CONTRACTOR OF THE CONTRACTOR				(	Fig. 6.
		in élevé loto–11			ptimum o–12	Gain faible Photo–13

Etape	Réglage de	l'oscilloscope	Points d'essai	Points de	Eléments contrôlés/	
No.	v	н	Folints G essai	réglage	spécifications de réglage	Procédure de réglage
10	Réglage	du gain d'a	lignement			and the second s
	CH1 (X), CH 50 mV/div, S (Sonde 10:1	5 mV/div	Axe X: TP1 Pin 3 (TŘ. IN) Axe Y: TP1 Pin 2 (TR. ER)	VR4 (TR. GA)	Différence de phase 90°  Pin3 (TR.IN) Pin5 (GND) Pin4 (TR.ER) 3 20kQ	L'alimentation étant coupée, connecte l'oscilloscope et l'oscillateur comme indiqué sur la Fig. 7.  Régler le mode de lecture normal.  Mettre l'oscillateur sous tension et le réglet pour sortir un signal 2 Vc-c, 1 kHz.  Remarque: (Certains oscillateurs sortent CC lorsqu'ils sont mis sous tension. Dans ce cas connecter l'oscillateur après l'avoir mis sous tension).  Ajuster VR4 (TR. GA: gain d'alignement) afin que la forme d'onde de choc sur l'oscilloscope devienne un cercle horizontal (différence de phase 90°).
11	Pho <b>Réglage</b>	n élevé oto–14 de la fréque	nce de relaxa	Gain opt Photo- tion du VCO	-15	Gain faible Photo-16  equence réglée par variation de
2	tension)		1			
			TP 2 Pin 2		Fréquence 4,275 MHz ± 0,025 MHz	<ul> <li>Régler le mode d'essai. (*)</li> <li>Coupler ASY et les fils GND en utilisant un tournevis à fente ou objet similaire.</li> <li>Connecter le fréquencemètre (gan me 10 MHz) à la broche 2 de TP 2.</li> <li>Ajuster VR8 (VCO. A) afin que le fréquencemètre indique 4,275 MHz ± 0,025 MHz.</li> </ul>

Etape No.	Réglage de l'oscilloscope		Points d'essai	Points de Eléments contrôlés/	Procédure de réglage	
	٧	Н		réglage	spécifications de réglage	· · · · · · · · · · · · · · · · · · · ·
12	Contrôl	e d'erreur de	mise au poin	it		
	1V/div	2 ms/div	TP1 Pin 6 (FO. ER)	Contrôle	Forme d'onde	<ul> <li>Régler le mode d'essai. (*)</li> <li>Connecter la broche 7 FO. IN (entrée de mise au point) de TP1 à GND.</li> <li>Appuyer sur la touche TRACK FWD et contrôler la forme d'onde à la broche 6 FO. ER (erreur de mise au point) de TP1 avec l'oscilloscope.</li> </ul>



Erreur de mise au point Photo-17

<sup>\*</sup> Voir Page 51.

# 7. AJUSTES

Realice los siguientes ajustes en el orden indicado:

### Ajustes

- 1. Ajuste de compensación del error de seguimiento, del error de foco y de RF
- 2. Ajuste de compensación del retorno de seguimiento
- 3. Comprobación de la sincronización del foco y del eje
- 4. Ajuste de la rejilla
- 5. Ajuste del equilibrio del seguimiento
- 6. Ajuste tangencial
- 7. Ajuste radial
- 8. Comprobación del nivel de RF
- 9. Ajuste de la ganancia de foco
- 10. Ajuste de la ganancia de seguimiento
- 11. Ajuste de la frecuencia propia del VCO (oscilador controlado por tensión)
- 12. Método de comprobación del error de foco

#### Dispositivos de Medición

- 1. Osciloscopio de doble trazo
- 2. Medidor de potencia lumínica
- 3. Disco de prueba YEDS-7
- 4 Filtro de ajuste de foco y seguimiento
- 5. Filtro de paso de banda para el ajuste de la ganancia de bucle.
- 6. Generador de señales
- 7. Destornillador de la rejilla
- 8. Herramientas de uso general
- 9. Disco disponible comercialmente (de 8 cm y de 12 cm)
- 10. Llave hex.(GGK 1002, 1.5 mm)

## ● Modo de prueba

### Activación y desacivation del mode de prueba

- ① Para activar el mode de prueba, ponga en ON el interruptor de alimentación con el puente del mode de prueba cortocircuitado.
- ② El modo de pruebga se desactivará poniendo el interrupter de alimentación en OFF.

Las funciones de las teclas en el modo de prueba se describen en la tabla 1.

### Descripción de los Resistores Variables Empleados para el Ajuste

VR2: Compensación de RF (RF. OF)

VR3: Ganancia de foco (FO. GA)

VR4: Ganancia de seguimiento (TR. GA)

VR5: Equilibrio de seguimiento (TR. BL)

VR6: Compensación del error de foco (FO. OF)

VR7: Compensación del error de seguimiento (TE. OF)

VR8: Contador de frecuencias del oscilador controlado por tensión (VCOA)

VR9: Compensación del retorno de seguimiento (TR. OF)

VR10: Nivel de RF (RF.LEV)





Fig.1 Punt de ajuste

# PD-S95, PD-95

En el modo de prueba, la apertura y cerrado de los servos se efectúa independientemente. Por lo tanto, para establecer el modo de reproduccion se deben cerrar los servos en orden serial. Recuerde que en el modo de prueba no se puede establecer el modo de reproducción pulsando simplemente la tecla PAUSE (

Por ejemplo, para establecer el modo de reproducción partiendo del modo de parada pulse las teclas siguientes en el orden indicado.



\* En el modo de prueba los servos siguen un orden serial.

# ● Función de Cada Tecla en el Modo de Prueba

Símbolo	Tecla	Función durante el modo de prueba	Explicación			
<b>&gt;&gt;</b>	TRACK FWD	Cerrar el servo del foco	Enciende el diodo laser y mueve el actuador del foco en direcció vertical para cerrar el servo del foco.			
<b>&gt;</b>	PLAY	Cerrar el servo del eje	Después de arrancar el motor del eje, cierre el servo en el modo CLV-H.			
11	PAUSE	Abrir/cerrar el servo de seguimiento	Ejecuta una conmutación. Al pulsar esta tecla se cierra el servo de seguimiento y la unidad entra en el modo de reproducción (los servos del foco y del eje deben estar cerrados previamente). En ese momento se enciende el indicador PAUSE. Si se la pulsa nuevamente, se abre el servo de seguimiento.			
	ОИТРИТ	Movimiento en retroceso (hacia dentro) del carro	Mueve el carro hacia dentro a alta velocidad (aprox. 1 cm/seg.). Dado que no existe un dispositivo de seguridad que detenga el carro, asegúrese de detenerlo manualmente a tiempo.			
	DISPLAY	Movimiento en avance (hacia fuera) del carro	Mueve el carro hacia fuera a alta velocidad (aprox. 1 cm/seg). Dado que no existe un dispositivo de seguridad que detenga el carro, asegúrese de detenerlo manualmente a tiempo.			
	STOP	Parada	Detiene todos los servos y hace que la unidad vuelva a su estado inicial.			
<b>A</b>	OPEN/CLOSE	Abrir/cerrar la bandeja del disco	Abre y cierra la bandeja del disco. Sin embargo, el lector no vuelve a la posición de reposo cuando se abre la bandeja y tampoco se mi eve al cerrarse la bandeja.			

Tabla 1.

Paso	Margen del	osciloscopio	Puntos de	Puntos de	item a probar/Especif. de	Procedimiento de ajuste
	V	Н	prueba	ajuste	ajuste	•
1	Ajuste de	e compensa	ción del erro	r de seguimie	ento, del error de	e foco y de RF
		TP1	TP1 Pin 4 (TR. ER)	VR7 (TE. OF)	0V ± 50 mV	<ul> <li>Establezca el modo de prueba (*)</li> <li>Ajuste VR7 (TE. OF: compensación del error de seguimiento) de forma que la tensión en el contacto 4 (TE: error de seguimiento) de TP1 sea 0V ± 50 mV.</li> </ul>
		TP1	TP1 Pin 6 (FO. ER)	VR6 (FO.OF)	0V ± 50 mV	Ajuste VR6 (FO. OF: compensación del error de foco) de forma que la tensión en el contacto 6 (FO. ER: error de foco) de TP1 sea 0V ± 50 mV.
		TP1	TP 1 Pin 1 (RF)	VR2 (RF. OF)	100 mV ± 50 mV	<ul> <li>Ajuste VR2 (RF. OF: compensación de RF de forma que la tensión de salida de RF el el contacto 1 de TP1 sea 100 mV ± 50 mV.</li> </ul>
2	Ajuste de	e compensa	ción del reto	rno de segui:	miento	
		TP1	TP1 Pin 2 (TR. RT)	VR9 (TR. OF)	0V ± 10 mV	<ul> <li>Establezca el modo de prueba. (*)</li> <li>Ajuste VR9 (TR. OF: compensación del retorno de seguimiento) de forma que la tensión en el contacto 2 (TR. RT: retorno de seguimiento) de TP1 sea 0V ± 10 mV.</li> </ul>
3	Comprot	pación de la	sincronizaci	ón del foco y	del eje	
	V 0.5V/div	H 100 msec /div	TP 1 Pin 1 (Salida de RF)		Salida de RF Rotación en sentido horario	Cargue el disco.     Establezca el modo de prueba. (*)     Aproxime el lector al centro del disco usando la tecla DISPLAY.     Asegúrese de efectuar esta operación.     Observe la salida de RF por el contacto 1 de TP 1 con un osciloscopio y confirme que la señal de RF sea emitida al pulsar la tecla TRACK FWD (▶►).     Pulse la tecla PLAY (▶) y confirme que el disco gira en sentido horario a aproximadamente la velocidad normal (unos 300 rpm por estar el lector cerca del centro del disco) sin que corra descontroladamente o en dirección inversa.

<sup>\*</sup> Vea la Página 66.

Paso	Margen dei	osciloscopio	Puntos de	Puntos de	item a probar/Especif. de	Procedimiento de ajuste
	V	н	prueba	ajuste	ajuste	1.0000111110110010011001100110011001100
4-1	Ajuste de	la rejilla (1	) (con un dis	co de 8 cm)		
	1V/div	5 ms/div	TP1 Pin 4 (TR. ER)	Rejilla	Punto nulo	<ul> <li>Este ajuste puede realizarse utilizando un disco de 8 cm con hoyos sobre un diámetro de 75 mm.</li> <li>Cargue el disco. (8 cm)</li> <li>Establezca el modo de prueba. (*)</li> <li>Pulse las teclas TRACK FWD (▶►) y PLAY (▶) en este orden para cerrar los servos del foco y del eje (el servo de seguimiento estará abierto).</li> <li>Pulse la tecla DISPLAY y mueva el lector a la pista externa del disco de 8 cm. Cuando mueva el lector, será posible introducir un destornillador en la ranura de la placa de ajuste de la rejilla desde la parte de arriba de la unidad. (Fig. 3)</li> <li>Observe la forma de la onda por el contacto 4 (TR. ER: error de seguimiento) de TP1 con un osciloscopio y, en ese</li> </ul>
	(T	TPI F	1.P.F. 0.001/	Lado de	el osciloscopio	momento, introduzca un filtro de corte pasabajos de 4 kHz. (Fig. 2)  Introduzca el destornillador de seguimiento en la ranura de ajuste y gírelo de forma que encuentre el punto nulo (Foto-1).

Paso	Margen de	l osciloscopio	Puntos de prueba	Puntos de ajuste	Item a probar/Especif. de	Procedimiento de ajuste
	V	Н		<u> </u>	ajuste	
4-2	Ajuste d	le la rejilla (2	) (con un dis	co de 12 cm	reproduciendo d	urante más de 60 minutos)
	1V/div	5 ms/div	TP1 Pin 4 (TR. ER)	Rejilla	Punto nulo	<ul> <li>Cargue el disco (reproduciendo durante más de 60 minutos).</li> <li>Establezca el modo de prueba. (*)</li> <li>Pulse las teclas TRACK FWD ( ▶►) ) y PLAY ( ▶►) en este orden para cerrar los servos del foco y del eje (el servo de seguimiento estará abierto).</li> <li>Pulse la tecla DISPLAY y mueva el lector a la pista externa del disco. Cuando mueva el lector, será posible introducir un destornillador en la ranura de la placa de ajuste de la rejilla desde la parte de arriba de la unidad. (Fig. 3)</li> <li>Observe la forma de la onda por el contacto 4 (TR. ER: error de seguimiento) de TP1 con un osciloscopio y, en ese momento, introduzca un filtro de corte pasabajos de 4 kHz. (Fig. 2)</li> </ul>
		Pin4 (TR.ER) Pin5 (GND)	L.P.F. 39k Ω 0.00	Lado	del osciloscopio	● Introduzca el destornillador de seguimiento en la ranura de ajuste y gírelo de forma que encuentre el punto nulo. (Foto-1)
			Fig. 2	2.		
				Rejilla	Amplitud máxima	● Gire el destornillador de la rejilla lentamente en sentido antihorario a partir del punto nulo y deténgase en el primer punto donde la amplitud de la onda (señal de error de seguimiento) sea máxima. (Vea Foto-2)

<sup>\*</sup> Vea la Página 66.




Fig. 3. Ajuste de la Rejilla




Foto-1 Punto nulo

Foto-2 Amplitud máxima




Foto-3 Fuera del punto nulo

Paso	Margen del	osciloscopio	Puntos de	Puntos de	Item a probar/Especif. de	Procedimiento de ajuste
	V	Н	prueba	aĵuste	ajuste	•
5	Ajuste d	el equilibrio	del seguimie	ento		
	0.5V/div	5 msec/div	TP1 Pin 4 (TR. ER)	VR5 (TR. BL)		Cargue el disco Establezca el modo de prueba. (*) Pulse la tecla DISPLAY y mueva el carro hasta cerca de la pista central del disco. Pulse las teclas TRACK FWD (▶►) y PLAY (▶) en ese orden para hacer girar el disco. Observe la forma de la onda por el contacto 4 (TR. ER: error de seguimiento) de TP1 con un osciloscopio y ajuste el VR5 (TR. BL: equilibrio de seguimiento) de forma que desaparezcan los elementos de CC de la onda del error de seguimiento.
	A		Foto-6	A≠8	A - + B -	A=B

<sup>\*</sup> Vea la Página 66.





Fig. 4. Ajuste Tangencial



Paso		osciloscopio	Puntos de prueba	Puntos de ajuste	Item a probar/Especif. de ajuste	Procedimiento de ajuste
	V	Н			4,000	
6	Ajuste tai	ngenciai	TP 1 Pin 1 (Salida de RF)	Tornillo de ajuste tangencial	Punto óptimo de la figura del ojo	<ul> <li>Cargue el disco.</li> <li>Establezca el modo de prueba. (*)</li> <li>Pulse la tecla DISPLAY y mueva el lector a la pista central del disco (colóquelo en un lugar tal que el tornillo de ajuste tangencial pueda verse desde arriba del servomecanismo. (Vea la Fig. 4)</li> <li>Pulse las teclas TRACK FWD (►►), PLAY (►) y PAUSE (■) en este orden para cerrar todos los servos. (Se enciende el indicador de pausa).</li> <li>Observe la salida de RF por el contacto 1 de TP 1 con un osciloscopio y ajuste el tornillo tangencial de forma que la figura del ojo se vea claramente. (Fig. 4)</li> <li>El punto de ajuste se encuentra cerca del punto medio entre el punto donde la figura del ojo se enturbia al girar el tornillo tangencial en sentido horario y el punto donde la figura del ojo se enturbia al girar el tornillo de ajuste en sentido antihorario. Observe la claridad general de la onda y una de las figuras del diamante en la figura del ojo (foto-9). El ajuste óptimo se obtiene donde las líneas de la figura del diamante son relativamente delgadas.</li> </ul>
					Pin5 (GND)	
						Fig. 5

<sup>\*</sup> Vea la Página 66.

Paso	Margen del c	osciloscopio	Puntos de	Puntos de	Item a probar/Especif. de	Procedimiento de ajuste
	V	Н	prueba	ajuste	ajuste	The section of the se
7	Ajuste rac	lial				
			TP1 Pin 1 (Salia de RF)	Tornillo de ajuste radial	Punto óptimo de la figura del ojo	<ul> <li>Cargue el disco.</li> <li>Establezca el modo de prueba. (*)</li> <li>Pulse la tecla DISPLAY y mueva el lector a la pista central del disco (colóquelo en un lugar tal que el tornillo de ajuste tangencial pueda verse desde arriba del servomecanismo. (Vea la Fig. 5)</li> <li>Pulse las teclas TRACK FWD (►►), PLAY (►) y PAUSE (■ ) en este orden para cerrar todos los servos. (Se enciende el indicador de pausa).</li> <li>Observe la salida de RF por el contacto 1 de TP1 con un osciloscopio y ajuste el tornillo radial de forma que la figura del ojo se vea claramente. (Fig. 4)</li> <li>El punto de ajuste se encuentra cerca del punto medio entre el punto donde la figura del ojo se enturbia al girar el tornillo radial en sentido horario y el punto donde la figura del ojo se enturbia al girar el tornillo de ajuste en sentido antihorario.</li> <li>Observe la claridad general de la onda y una de las figuras del diamante en la figura del ojo (foto-9). El ajuste óptimo se obtiene donde las líneas de la figura del diamante son relativamente delgadas.</li> <li>Efectúe los ajustes tangencial y radial alternativamente dos o más veces.</li> </ul>
					Pin5 (GND)	
						Fig. 5

<sup>\*</sup> Vea la Página 66.

Paso	Margen del osciloscopio		Puntos de	Puntos de	item a probar/Especif. de	Procedimiento de ajuste
Pasu	V	н	prueba	a ajuste	ajuste	-
8	Comprob	ación del n	ivel de RF			
			TP1 Pin 1 (RF) TP1 Pin 1 (RF)	Comprobación VR 10	1.5V +0.2V -0V 1.5V +0.2V -0V	<ul> <li>Establezca el modo de prueba. (*)</li> <li>Conecte la sonda del osciloscopio al contacto 1 (salida de RF) de TP 1.</li> <li>Reproduzca el disco, mida la tensión p-p de la onda de RF y confirme que sea 1.5V +0.2V .</li> <li>Ajuste VR 10 si la tensión no es 1.5V +0.2V .</li> </ul>

<sup>\*</sup> Vea la Página 66.

Paso	Margen de	osciloscopio	Puntos de	Puntos de	item a probar/Especif. de	Procedimiento de ajuste
	٧	н	prueba	ajuste	ajuste	r rocodimento de ajuste
9	Ajuste d	e la gananci	ia de foco			
	CH1 (X) , Cl 20 mV/div, 5 (Sonda 10:1	mV/div	Eje X: TP1 Pin 5 (FO. IN) Eje Y: TP1 Pin 6 (FO. ER)	VR3 (FO. GA)	Diferencia de fase de 90°	<ul> <li>Con la unidad apagada, conecte el osciloscopio y el oscilador como muestra la Fig. 6.</li> <li>Establezca el modo de reproducción normal.</li> <li>Encienda el oscilador y ajústelo para que emita una señal de 1,2 kHz, 1 Vp-p.</li> <li>Nota: Algunos osciladores emiten CC al ser encendidos. En este caso, encienda el oscilador antes de conectarlo.</li> <li>Ajuste VR3 (FO, GA: ganancia de loco) de forma que la onda de resurgimiento en el osciloscopio se convierta en un círculo horizontal (diferencia de fase de 90°).</li> </ul>
					( :0	Fig. 6.
		anancia		Ganancia	óptima	Baja ganancia

Foto-12

Foto-13

Foto-11

Dana	Margen del	osciloscopio	Puntos de	Puntos de	ltem a probar/Especif. de	Procedimiento de ajuste
Paso	V	н	prueba	ajuste	ajuste	,
10	Ajuste de	e la gananc	ia de seguimi	iento		
	CH1 (X), CF 50 mV/div, 8 (Sonda 10:1	5 mV/div	Eje X: TP1 Pin 3 (TR. IN) Eje Y: TP1 Pin 2 (TR. ER)	VR4 (TR. GA)	Diferencia de fase de 90°  IPI  Pin3 (TRIN)  Pin5 (GND)  Pin4 (TR.ER)	Con la unidad apagada, conecte el osciloscopio y el oscilador como muestra la Fig. 7.  Establezca el modo de reproducción normal.  Encienda el oscilador y ajústelo para que emita una señal de 1 kHz, 2 Vp-p.  Nota: Algunos osciladores emiten CC al sel encendidos. En este caso, encienda e oscilador antes de conectarlo.  Ajuste VR4 (TR, GA: ganancia de seguimiento) de forma que la onda de resurgimiento en el osciloscopio se convierta en un círculo horizonta (diferencia de fase de 90°).
					20k Ω	
		ganancia oto-14			ia óptima o–15	Baja ganancia Foto–16
	F	oto-14	ncia propia d	Foto	0–15	Foto-16
11	F	oto-14	ncia propia d	Foto		Foto-16

<sup>\*</sup> Vea la Página 66.

٧	Н	prueba	gen del osciloscopio Puntos de Puntos de	Item a probar/Especif. de	Proceediminate de afrat
		p. 1000	ajuste	ajuste	Procedimiento de ajuste
Compro	bación del e	rror de foco			
1V/div	2 ms/div	TP1 Pin 6 (FO. ER)	Comprobación	Forma de onda	<ul> <li>Establezca el modo de prueba. (*)</li> <li>Conecte a tierra el contacto 7 (FO. IN: entrada de foco) de TP1.</li> <li>Pulse la tecla TRACK FWD y compruebe la forma de la onda en el contacto 6 (FO. ER: error de foco) de TP1 con un osciloscopio.</li> </ul>
				1V/div 2 ms/div TP1 Pin 6 Comprobación	1V/div 2 ms/div TP1 Pin 6 Comprobación Forma de onda

<sup>\*</sup> Vea la Página 66.

# 8. IC INFORMATION

• The information shown in the list is basic information and may not correspond exactly to that shown in the schematic diagrams.

# 8.1 PD0116A (IC513)

# • DIGITAL FILTER

# **Pin Function Table**

Pin No.	Pin Name	1/0	Pin Function				
1	DATA	ı	Serial data input (16-bit, 2 complement, MSB first)				
2	ВСК	I	Bit clock input for input data				
3	CKS	ı	XIN (master clock) frequency selection H=384 fs, L=256 fs				
4	(NC)	(1)					
5	CKEN	ı	Crystal oscillation circuit operation control H=Oscillation, L=Stop				
6	XIN	ı	Crystal oscillation circuit input or external clock input				
7	XOUT	0	Crystal oscillation circuit output				
8	VSS1	-	GND terminal 1				
9	скоит	0	Master clock output (Frequency is the same as XIN)				
10	CHS	1	Playback data channel selection (During 1 ch playback mode) H=Lch, L=Rch				
11	MDCK	ı	Clock input for microprocessor data				
12	MDATA	ı	Microprocessor data input				
13	MDLE	1	Latch enable signal input for microprocessor data				
14	RST	ı	System reset	H=Normal operation, L=Reset			
15	LRS		LR clock polarity selection	H L	LRCK H L Lch Rch Rch Lch		
16	OBS1	1		OBS1	OBS2	Bit length	
17	OBS2	ı	Output data bit length selection	H L L	H L	18 20 19+1	
18	SMUTE	1	Soft mute control H=OFF, L=ON				
19	IPFS	1	Interpolation function selection Fixed	to L			
20	PLYS	1	Playback channel mode selection H=2c	H=2ch playback, L=1ch playback			
21	VSS2	-	GND terminal 2	<del></del>	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
22	VDD	-	+5V power supply terminal				
23	RDOUT	0	Rch serial data output (During 1ch playback mode, serial data output) (2 complement, MSB first)				
24	LDOUT	o	Lch serial data output (During 1ch playback mode, "L" fixed output) (2 complement, MSB first)				
25	WOUT	0	Word clock output				
26	BOUT	0	Bit clock output for output data				
27	MDS	ı	Mode setting method selection H=Terminal control, L=Microprocessor control				
28	LRCK	1	LR clock input				

<sup>\*</sup>Input terminals other than XIN come with pull-up resistor.

# 9. DISASSEMBLY

# 9.1 PLACING THE ANALOG BOARD ASSEMBLY UPRIGHT (PD-95 only)

- 1. Remove the connectors. (5 in front and 4 behind)
  - 3 from the audio transformer (A)
  - 2 from the main board ( (B))
  - 1 from both analog boards-2 altogether ( ( )
  - 1 from the L and R jacks respectively-2 altogether ( ( )
- 2. Remove the ground lead wire.
- 3. Remove the screws of the board.
- 4. Remove the audio case.
- 5. Insert the analog board assembly into the holder of the front panel, and place it upright.
- 6. Re-insert the connectors.
- When placing the analog board upright, ground one ground wire to the plate of the unit using an alligator clip extension cable.




Fig. 1

# 9.2 PLACING THE MAIN BOARD ASSEMBLY UPRIGHT

Perform this after removing the analog board. (PD-95 only)

- 1. Remove the two screws ① of the DIGITAL OUT section on the rear side.
- 2. Remove all the screws of the main board assembly.
- Remove the flexible cable from the input.
   (Be especially careful as this cable breaks easily.)
- 4. Insert the main board assembly into the slit of the base plate.
- 5. Re-insert the flexible cable and connectors.





Fig. 3



Main board assembly





Fig. 4

# 10. PANEL FACILITIES



- 1 POWER switch
- ② DISPLAY button and OFF indicator
- ③ OUTPUT button and DIGITAL/ANALOG indicators (PD-S95: OPTICAL/COAXIAL indicators)
- (4) Remote sensor
  Receives the signal from the remote control unit.
- ⑤ Disc tray
- ⑥ Stop button (■)
- ⑦ Track search buttons (I◄◄/►►I)

- 1 Pause button (II) and indicator

# 11. SPECIFICATIONS

#### 1. General

Туре	Compact disc digital audio system
Power requirements	
European model	AC 220 - 230 V, 50/60 Hz
U.K. and Australian models .	AC 230 - 240 V, 60 Hz
U.S. and Canadian models	AC 120 V, 60Hz
Other modelsAC 11	0/120 - 127/220/240 V (Switchable),
	50/60 Hz
Power consumption	
PD-95	30 W
PD-S95	22 W
Operating temperature	+5°C - +35°C
	+41°F - +95°F
Weight	
	20.0 kg (44 lb)
PD-S95	17.5 kg (38 lb, 6 oz)
External dimensions	440(W) X 433(D) X 151(H) mm
17-5	/16(W) X 17-1/16(D) X 5-15/16(H) in

#### 2. Audio section

#### PD-95

Frequency response	2 Hz - 20 kHz
S/N ratio	112 dB or more (EIAJ)
	98 dB or more (EIAJ)
Channel separation	108 dB or more (EIAJ)
Harmonic distortion	0.0018% or less (EIAJ)
	2.0V
Wow and flutter	Limit of measurement
	(±0.001% W.PEAK) or less (EIAJ)
Channels	2-channel (stereo)
Balanced type audio line out	
(U.S. and Canadian models)	2V (600 Ω)
PD-S95	
Wow and flutter	Limit of measurement
	(±0.001% W.PEAK) or less (EIAJ)

### 3. Output terminal

Unbalanced type audio line output jacks (PD-95 only)
Balanced type audio line output jacks (PD-95 only)
Optical and coaxial digital output jacks (BNC type coaxial digital output jack (PD-S95 only))

Control input/output jacks (U.S. and Canadian models only)

### 4. Functions

Basic operation buttons

PLAY, PAUSE, STOP

#### Search function

- Direct play
- Track search
- Manual search
- Index search
- Time location

#### Programming

- Maximum 24 steps
- Pause
- Program check/correction
- Program clear (single track or all tracks)

### Repeat functions

- 1 track repeat
- All tracks repeat
- Program play repeat
- Random play repeat
- Program random play repeat

Random play (repeat also available)

### Switching display

Time consumed, remaining time (track/disc), and total time

Timer start

### 5. Accessories

•	Remote control unit	1
•	Size AAA/R03 dry batteries	2
•	Turntable sheet	1
•	Control cord (U.S. and Canadian models only)	1
•	Output cable (PD-95 only)	1
•	Operating instructions	1
•	Coaxial output cable (PD-S95 only)	1
•	Ground lead unit (PD-S95 only)	1

#### NOTE

Specifications and design subject to possible modification without notice, due to improvements.

### **POWER-CORD CAUTION**

Handle the power cord by the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or electric shock. Do not place the unit, a piece of furniture, etc., on the power cord, or pinch thecord. Never make a knot in the cord or tie it with other cords. The power cords should be routed such that they are not likely to be stepped on. A damaged power cord can cause fire or give you an electrical shock. Check the power cord once in a while. When you find it damagel, ask your nearest PIONEER authorized service center or your dealer for a replacement.